



# Fischer Panda

## Operation manual

Description of the generator and operation manual



### **Panda 8000NE PMS Digital** Super silent technology

230V - 50Hz / 120V - 60Hz / 7kW

**Icemaster Fischer Panda**

## Current revision status

	Document
Actual:	Panda_8000NE_PMS_Digital_s00860_Operation manual.V01_24.8.05
Replace:	

Revision	Page

				
since 1977 Icemaster GmbH	since 1978 Fischer Marine Generators	since 1988 Conclusion Fischer - Icemaster GmbH	since 1988 100 % water cooled Panda generators	since 1988 Panda Vehicle Generators

**Fischer Panda**

FISCHER GENERATORS have been manufactured since 1978 and are a well-known brand for first class diesel generators with especially effective sound-insulation.

Fischer has been one of the leading manufacturers in respect of quality and know-how during this period.

FISCHER, as the worldwide manufacturer of modern marine diesel generators, developed the Sailor-Silent series for example and produced a GFK sound-insulated capsule as early as 1979 and the basis for new generator technology.

The companies Fischer and Icemaster amalgamated under the direction of Icemaster in 1988, in order to concentrate on the development of new products. Production was moved to Paderborn.

The amalgamation of the two qualified companies led to the development of a complete new programme within a short space of time. The gensets developed at that time set new technological standards worldwide.

The gensets became more efficient and powerful than other gensets in the same nominal performance range, because of the improved cooling. Panda generator demonstrated its superiority in several tests by renowned institutes and magazines during the past years. The patented VCS (voltage Control System) means it can meet all demands including motor speed. The start-booster (ASB) means Panda generators meet the highest demands in respect of voltage stability and starting values A Panda generator, with the same drive motor, produces 15% more effective output than the majority of conventional generators. This superiority in efficiency also ensures a fuel saving to the same extent.

The 100% water-cooled Panda genset are currently manufactured in the performance range from 2 to 100 kW in various versions. Fast running motors are preferred for performances up to approx 30 kW (Nominal speed 3000 rpm). The heavier slow runners are preferred for the higher range. The fast running gensets have proved themselves many times for many uses, that they meet the demands in quality of yachts and vehicles, and offer space and weight saving of 50% compared to slow running generators.

In addition to the Panda series, Icemaster also supply the super compact high-tech sound-insulated battery charging genset from the DC/AC Panda AGT series, which is a very interesting solution for the production of mobile power.

The new HTG-alternators ensure that a charging rate of 285 amps is achieved that was scarcely thought possible for this compact construction. This alternator replaces a separate shipboard generators (constant 230 volts AC with up to 3500 kW from the main machine)

ICEMASTER GmbH, 33104 Paderborn, reserves all rights regarding text and graphics. Details are given to the best of our knowledge. No liability is accepted for correctness. Technical modifications for improving the product without previous notice may be undertaken without notice. Before installation, it must be ensured that the Pictures, diagrams and related material are applicable to the genset supplied. Enquiries must be made in case o doubt.

# Safety first

These symbols are used throughout this manual and on labels on the machine itself to warn of the possibility of personal injury. Read these instructions carefully. It is essential that you read the instructions and safety regulations before you attempt to assemble or use unit.

	<p>This danger symbol refers to toxic danger and draws attention to special warnings, instructions or procedures which, if not strictly observed, may result in severe personal injury or loss of life.</p>
	<p>This danger symbol refers to electric danger and draws attention to special warnings, instructions or procedures which, if not strictly observed, may result in electrical shock which will result in severe personal injury or loss of life.</p>
	<p>This danger symbol refers to electric danger and draws attention to special warnings, instructions or procedures which, if not strictly observed, may result in electrical shock which will result in severe personal injury or loss of life.</p>
	<p>This warning symbol draws attention to special warnings, instructions or procedures which, if not strictly observed, may result in damage or destruction of equipment, severe personal injury or loss of life.</p>
	<p>This warning symbol draws attention to special warnings, instructions or procedures which, if not strictly observed, may result in damage or destruction of equipment</p>

# Tools

This symbols are used throughout this manual to show which tool must be used at maintenance or installation.



Spanners  
X = number of spanner



Hook wrench for oil filter



Screw driver, for slotted head screws and for recessed head screws



Multimeter, multimeter with capacitor measuring



Socket wrench set



Hexagon wrench keys

# CALIFORNIA

## Proposition 65 Warning

**Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.**



### Attention, Important Directions regarding Operation!

1. The installation certificate must be completed when taken into use, and certified by a signature.
2. The installation certificate must be despatched within two weeks of use to ICEMASTER.
3. The official guaranty confirmation will be completed by ICEMASTER after receipt and sent to the customer.
4. A guaranty must be shown to make any claims.

Claims against the guaranty will not be accepted if the above said instructions are not, or only partially, carried out.

### Manufacturer declaration in terms of the machine guideline 98/37/EG .

The generator is in such a way developed that all assembly groups correspond to the CE guidelines. If machine guideline 98/37/EG is applicable, then it is forbidden to bring the generator into operation until it has been determined that the system into which the generator is to be installed in also corresponds to the regulations of the machine guideline 98/37/EG. This concerns among other things the exhaust system, cooling system and the electrical installation.

The evaluation of the "protection against contact" can only be accomplished in connection with the respective system. Likewise among other things responsibility for correct electrical connections, a safe ground wire connection, foreign body and humidity protection, protection against humidity due to excessive condensation as well as the overheating through appropriate and inappropriate use in its installed state on the respective machine lies within the responsibility of those who undertake installation of the generator in the system.

Use the advantages of the customer registration:

- Thus you receive to extended product informations, which are sometimes safety-relevant
- you receive, if necessarily free Upgrades

Far advantages:

By your full information Fischer Panda technicians can give you fast assistance, since 90% of the disturbances result from errors in the periphery.

Problems due to errors in the installation can be recognized in the apron.

Technical Support by Internet: [info@fischerpanda.com](mailto:info@fischerpanda.com)

# Safety Precautions



**The electrical Installations may only be carried out by trained and tested personnel!**

**The generator may not be taken into use with the cover removed.**

The rotating parts (belt-pulley, belts, etc) must be so covered and protected do that there is no danger to life and body!

If a sound insulation covering must be produced at the place of installation, then well-placed signs must show that the generator can only be switched on with a closed capsule.

All servicing-, maintenance or repair work may only carried out, when the motor is not running.

Electrical voltages above 48 volts ( battery chargers greater than 36 volts) are always dangerous to life). The rules of the respective regional authority must be adhered to. Only an electrician may carry out installation of the electrical connections for safety reasons.

## **Protective Conductor:**

The generator is „earthed " as standard (The centre and earth are connected by means of a bridge in the generator terminal box). This is a basic safety function, which offers basic safety as long as no other component has been installed. It is, above all, conceived for supply and an eventual test run.

This "earth" (PEN) is only effective, if all parts of the electrical system is earthed, and has a common "potential". The bridges can be removed, if this is required for technical reasons and another protection system has been installed.

**The full voltage is exploited at the AC control box, when the generator is run. It must therefore be ensured that the control box is closed and cannot be tampered with, if the generator is running.**

**The battery must always be disconnected, if work on the generator or electrical system is to be carried out, so that the generator cannot be unintentionally started.**

## **Switch off all load when working on the generator**

All load must be disconnected, in order to avoid damages to the devices. In addition the semi conductors in the AC control box must be disconnected in order to avoid the boat capacitors being activated. The minus pole of the battery ought to be removed.

Capacitors are required to run the generator. These have two varying functions:

A) The working capacitors

B) The (Booster) capacitors

Both Groups are located in a sound cover of the genset.

Capacitors are electrical stores. There could be a residual of high electrical current at the contacts for a period disconnection from the circuit. The contacts my not be touched for safety reasons, If the capacitors are to be exchanged or checked, then a short circuit between the contacts should be made so that the stored energy is discharged.

If the generator is switched off in the normal manner, the working capacitors are automatically discharged by means of the windings. The booster capacitors are discharged by means of internal discharge resistors.

All capacitors must be short-circuited before work is carried out on the AC-Control box for safety reasons.



## Table of Contents


<b>Current revision status .....</b>	<b>ii</b>
<b>Safety first.....</b>	<b>iv</b>
<b>Tools .....</b>	<b>v</b>
<b>Safety Precautions .....</b>	<b>vii</b>
<b>A The Panda Generator .....</b>	<b>3</b>
<b>A.1 Description of the Generator .....</b>	<b>3</b>
A.1.1 Right Side View - Panda 8000 NE 50Hz .....	3
A.1.2 Left Side View - Panda 8000 NE 50Hz .....	4
A.1.3 Front View - Panda 8000 NE 50Hz .....	5
A.1.4 Back View - Panda 8000 NE 50Hz.....	6
A.1.5 View from Above - Panda 8000 NE 50Hz .....	7
A.1.6 Right Side View - Panda 8000 NE 60Hz .....	8
A.1.7 Left Side View - Panda 8000 NE 60Hz .....	9
A.1.8 Front View - Panda 8000 NE 60Hz .....	10
A.1.9 Back View - Panda 8000 NE 60Hz.....	11
A.1.10 View from Above - Panda 8000 NE 60Hz .....	12
<b>A.2 Details of functional units .....</b>	<b>13</b>
A.2.1 Remote control panel .....	13
A.2.2 Components of Cooling System (Raw water ) .....	14
A.2.3 Components of Cooling System (Freshwater) .....	16
A.2.4 Components of the fuel system.....	20
A.2.5 Components of combustion air.....	22
A.2.6 Components of the electrical system .....	25
A.2.7 Sensors and switches for operating surveillance .....	34
A.2.8 Components of the oil circuit.....	38
<b>A.3 Operation instructions .....</b>	<b>39</b>
A.3.1 Preliminary remark .....	39
A.3.2 Daily routine checks before starting .....	40
A.3.3 Starting Generator.....	41
A.3.4 Stopping the Generator .....	41
<b>B Remote control panel .....</b>	<b>43</b>

Intentionally Blank


## A. The Panda Generator

### A.1 Description of the Generator

#### A.1.1 Right Side View - Panda 8000 NE 50Hz




- |   |   |
|---|---|
| 01. Thermostat housing                              | 14. Exhaust connection                                  |
| 02. 12V DC-alternator                               | 15. Exhaust output                                      |
| 03. V-belt for DC-alternator and cooling water pump | 16. Connection external ventilation valve               |
| 04. Engine oil filter                               | 17. Intake to external cooling water expansion tank     |
| 05. Oil pressure switch                             | 18. Backflow from external cooling water expansion tank |
| 06. Sound cover - base part                         | 19. Thermo-sensor raw water out                         |
| 07. Power terminal box with measuring board         | 20. Generator housing with coil                         |
| 08. Starter motor                                   | 21. Injector for raw water                              |
| 09. Solenoid switch for starter motor               | 22. Solid state relay for booster capacitor             |
| 10. Water-cooled exhaust elbow                      | 23. Booster capacitor (1x60 $\mu$ F)                    |
| 11. Freshwater return pipe                          | 24. Excitation capacitors (4x50 $\mu$ F)                |
| 12. Thermo-sensor freshwater out                    | 25. Cooling water filler neck                           |
| 13. Thermo-sensor exhaust                           |   |


**A.1.2 Left Side View - Panda 8000 NE 50Hz**


- |   |   |
|---|---|
| 01. Excitation capacitors (4x50 $\mu$ F)          | 14. Raw water pump  |
| 02. Charge control for DC-alternator              | 15. Raw water intake hose                                     |
| 03. Air suction housing with air filter           | 16. Fuel filter   |
| 04. Failure bypass switch                         | 17. Raw water inlet   |
| 05. Air suction hose to induction elbow           | 18. Thermo-sensor freshwater in                               |
| 06. Fuel solenoid valve                           | 19. Power relays  |
| 07. Stop solenoid                                 | 20. Electrical fuses  |
| 08. Ventilation screw thermostat housing          | 21. Cooling water pipe, connection block - cooling water pump |
| 09. Ventilation screw internal cooling water pump | 22. Control box   |
| 10. Pulley for internal cooling water pump        | 23. Fuse for DC-system (30A)                                  |
| 11. Actuator for speed control                    | 24. Sound cover - base part                                   |
| 12. Oil dipstick                                  |   |
| 13. Cooling water connection block                |   |

A.1.3 Front View - Panda 8000 NE 50Hz




- |  |   |
|--|---|
| 01. Ventilation screw thermostat housing                     | 12. Injection hose, freshwater from external expansion tank |
| 02. Ventilation screw internal cooling water pump            | 13. Fuel filter   |
| 03. Thermostat housing with thermostat set                   | 14. Control box   |
| 04. Pulley for internal cooling water pump                   | 15. Raw water inlet   |
| 05. 12V DC-alternator  | 16. Fuel intake connection                                  |
| 06. V-belt for DC-alternator and internal cooling water pump | 17. Fuel backflow connection                                |
| 07. Raw water pump   | 18. Cable fuel pump   |
| 08. Freshwater intake pipe                                   | 19. Oil drain hose  |
| 09. Hose for raw water intake                                | 20. Cable for fuel level sensor                             |
| 10. Engine oil filter  | 21. Passage for cable starter battery minus (-)             |
| 11. Oil pressure switch                                      | 22. Passage for cable starter battery plus (+)              |


**A.1.4 Back View - Panda 8000 NE 50Hz**


- |   |   |
|---|---|
| 01. Cooling water filler neck               | 09. Cover for oil-cooled bearing                        |
| 02. Booster capacitor (1x60 $\mu$ F)        | 10. Control box   |
| 03. Water-cooled exhaust elbow              | 11. Passage for cable control panel                     |
| 04. Air suction housing with air filter     | 12. Connection external ventilation valve               |
| 05. Excitation capacitors (4x50 $\mu$ F)    | 13. Intake to external cooling water expansion tank     |
| 06. Solid state relay for booster capacitor | 14. Backflow from external cooling water expansion tank |
| 07. Generator front cover                   | 15. Passage for cable load                              |
| 08. Fuse for DC-system (30A)                |   |

A.1.5 View from Above - Panda 8000 NE 50Hz




- |  |   |
|--|---|
| <ul style="list-style-type: none"> <li>01. Solid state relay for booster capacitor</li> <li>02. Booster capacitor (1x60<math>\mu</math>F)</li> <li>03. Cooling water filler neck</li> <li>04. Ventilation hose to external expansion tank</li> <li>05. Water-cooled exhaust elbow</li> <li>06. Engine oil filler neck</li> <li>07. 12V DC-alternator</li> <li>08. Ventilation screw thermostat housing</li> <li>09. Excitation capacitors (4x50<math>\mu</math>F)</li> <li>10. Charge control for DC-alternator</li> </ul> | <ul style="list-style-type: none"> <li>11. Air suction housing with air filter</li> <li>12. Control box</li> <li>13. Cylinder head thermo-switch</li> <li>14. Air suction hose to induction elbow</li> <li>15. Actuator</li> <li>16. Fuel solenoid valve</li> <li>17. Stop solenoid</li> <li>18. Ventilation screw internal cooling water pump</li> <li>19. Pulley for internal cooling water pump</li> </ul> |
|--|---|


**A.1.6 Right Side View - Panda 8000 NE 60Hz**


- |   |   |
|---|---|
| 01. Thermostat housing                              | 13. Thermo-sensor exhaust                               |
| 02. 12V DC-alternator                               | 14. Exhaust connection                                  |
| 03. V-belt for DC-alternator and cooling water pump | 15. Exhaust output                                      |
| 04. Engine oil filter                               | 16. Connection external ventilation valve               |
| 05. Oil pressure switch                             | 17. Intake to external cooling water expansion tank     |
| 06. Sound cover - base part                         | 18. Backflow from external cooling water expansion tank |
| 07. Power terminal box with measuring board         | 19. Thermo-sensor raw water out                         |
| 08. Starter motor                                   | 20. Generator housing with coil                         |
| 09. Solenoid switch for starter motor               | 21. Injector for raw water                              |
| 10. Water-cooled exhaust elbow                      | 22. Solid state relays for booster capacitors           |
| 11. Freshwater return pipe                          | 23. Booster capacitors (2x40µF)                         |
| 12. Thermo-sensor freshwater out                    | 24. Cooling water filler neck                           |

A.1.7 Left Side View - Panda 8000 NE 60Hz




- |   |   |
|---|---|
| <ul style="list-style-type: none"> <li>01. Excitation capacitors (4x50<math>\mu</math>F)</li> <li>02. Charge control for DC-alternator</li> <li>03. Air suction housing with air filter</li> <li>04. Failure bypass switch</li> <li>05. Air suction hose to induction elbow</li> <li>06. Fuel solenoid valve</li> <li>07. Stop solenoid</li> <li>08. Ventilation screw thermostat housing</li> <li>09. Ventilation screw internal cooling water pump</li> <li>10. Pulley for internal cooling water pump</li> <li>11. Actuator for speed control</li> <li>12. Oil dipstick</li> <li>13. Cooling water connection block</li> </ul> | <ul style="list-style-type: none"> <li>14. Raw water pump</li> <li>15. Raw water intake hose</li> <li>16. Fuel filter</li> <li>17. Raw water inlet</li> <li>18. Thermo-sensor freshwater in</li> <li>19. Power relays</li> <li>20. Electrical fuses</li> <li>21. Cooling water pipe, connection block - cooling water pump</li> <li>22. Control box</li> <li>23. Fuse for DC-system (30A)</li> <li>24. Sound cover - base part</li> </ul> |
|---|---|


**A.1.8 Front View - Panda 8000 NE 60Hz**


- |  |   |
|--|---|
| 01. Ventilation screw thermostat housing                     | 12. Injection hose, freshwater from external expansion tank |
| 02. Ventilation screw internal cooling water pump            | 13. Fuel filter   |
| 03. Thermostat housing with thermostat set                   | 14. Control box   |
| 04. Pulley for internal cooling water pump                   | 15. Raw water inlet   |
| 05. 12V DC-alternator  | 16. Fuel intake connection                                  |
| 06. V-belt for DC-alternator and internal cooling water pump | 17. Fuel backflow connection                                |
| 07. Raw water pump   | 18. Cable fuel pump   |
| 08. Freshwater intake pipe                                   | 19. Oil drain hose  |
| 09. Hose for raw water intake                                | 20. Cable for fuel level sensor                             |
| 10. Engine oil filter  | 21. Passage for cable starter battery minus (-)             |
| 11. Oil pressure switch                                      | 22. Passage for cable starter battery plus (+)              |

A.1.9 Back View - Panda 8000 NE 60Hz



- |   |   |
|---|---|
| 01. Cooling water filler neck                 | 09. Cover for oil-cooled bearing                        |
| 02. Booster capacitors (2x40 $\mu$ F)         | 10. Control box   |
| 03. Water-cooled exhaust elbow                | 11. Passage for cable control panel                     |
| 04. Air suction housing with air filter       | 12. Connection external ventilation valve               |
| 05. Excitation capacitors (4x50 $\mu$ F)      | 13. Intake to external cooling water expansion tank     |
| 06. Solid state relays for booster capacitors | 14. Backflow from external cooling water expansion tank |
| 07. Generator front cover                     | 15. Passage for cable load                              |
| 08. Fuse for DC-sysetm (30A)                  |   |


**A.1.10 View from Above - Panda 8000 NE 60Hz**


- |   |   |
|---|---|
| <ul style="list-style-type: none"> <li>01. Solid state relays for booster capacitors</li> <li>02. Booster capacitors (2x40<math>\mu</math>F)</li> <li>03. Cooling water filler neck</li> <li>04. Ventilation hose to external expansion tank</li> <li>05. Water-cooled exhaust elbow</li> <li>06. Engine oil filler neck</li> <li>07. 12V DC-alternator</li> <li>08. Ventilation screw thermostat housing</li> <li>09. Excitation capacitors (4x50<math>\mu</math>F)</li> <li>10. Charge control for DC-alternator</li> </ul> | <ul style="list-style-type: none"> <li>11. Air suction housing with air filter</li> <li>12. Control box</li> <li>13. Cylinder head thermo-switch</li> <li>14. Air suction hose to induction elbow</li> <li>15. Actuator</li> <li>16. Fuel solenoid valve</li> <li>17. Stop solenoid</li> <li>18. Ventilation screw internal cooling water pump</li> <li>19. Pulley for internal cooling water pump</li> </ul> |
|---|---|

## A.2 Details of functional units

### A.2.1 Remote control panel


The remote control panel is equipped with some new monitoring functions, which increases the operational safety of the generator. A failure message is shown over contacts which are normally closed. If a connection is intermitted triggers this a failure message.



- |  |  |
|--|--|
| 01. Digital display                        | 04. S3 Button „Screen shift“                     |
| 02. S1 Button „ON/OFF“ „Stand by“          | 05. S4 Button „rpm Shift n1/n2“                  |
| 03. S2 Button „Alarm mute / Program level“ | 06. S5 Button „Generator run/stop / Select Save“ |

Fig. A.1: Remote control panel


**A.2.2 Components of Cooling System (Raw water )**



**Raw water intake**

The diagram shows the supply pipes for the generator. The connection neck for the raw water connection is shown on the left hand side. The cross-section of the intake pipe should be nominally larger than the generator connection.


Fig. A.2: Raw water intake



**Raw water impeller pump**

The raw water pump is fitted with a rubber impeller. This pump is self-inductive. If, for example, you forget to open the sea valve, then you must expect the impeller to be destroyed after a short period of time. It is recommended to store several impellers on board as spare parts.

Fig. A.3: Raw water impeller pump



**Heat exchanger**

Separates the raw water system from the freshwater system.

Fig. A.4: Heat exchanger

**Ventilation valve**

A siphon must be installed if the generator sinks below the water line because of the rocking of the boat, even if it is only for a short period of time. A hosepipe on the generator casing has been produced for this. Both connecting pieces are bridged by a formed piece of hose.




Fig. A.5: Connection external vent valve

**Raw water injector nozzle**

The injection point for the marine generator water-cooled exhaust system is situated at the exhaust connection pieces. The exhaust connections must be regularly checked for signs of corrosion.





Fig. A.6: Raw water injector nozzle


**A.2.3 Components of Cooling System (Freshwater)**



**Cooling water filler neck**

The cooling water filler neck is situated at the water-cooled manifold and only used, when the generator is initially started. Since the generator is normally already filled with cooling water, these components are only by the user, if repairs are to be carried out. Topping up with cooling water may only carried out at the external cooling water compensation tank. Note that the water level in the cooling water compensation tank is only 20% of the volume in a cold state.


Fig. A.7: Cooling water filler neck



**Freshwater backflow**

The cooling water is fed to the heat exchanger from the water-cooled manifold by means of the pipe shown in the diagram.

Fig. A.8: Freshwater backflow



**Ventilation pipe**

The ventilation pipe at the water-cooled exhaust manifold leads to the external expansion tank. This pipe only serves as a ventilation pipe, if both pipes are to be connected to the external expansion tank (ventilation pipe and intake pipe).

Fig. A.9: Ventilation pipe

**Hose connection pieces for the external expansion tank**

The external expansion tank is connected by two hose connections. The connecting pieces shown here serves as constant ventilation for the water-cooling system.

In case the external expansion tank is connected with two hoses, the system will ventilate itself. In this case, additional ventilation is only necessary when the generator is initially filled, or if the cooling water is not circulating.




Fig. A.10: External expansion tank

**Heat exchanger**

Separates the raw water system from the freshwater system.




Fig. A.11: Heat exchanger

**Cooling water connection block**

The cooling water is fed to the generator and drained via the cooling water connection block. The cooling water connection block consists of an aluminium alloy, which can behave like a sacrificial anode.




Fig. A.12: Cooling water connection block




Fig. A.13: Cooling water pipe




Fig. A.14: Internal cooling water pump




Fig. A.15: Internal cooling water pump



#### Ventilation screw cooling water pump

The ventilation screw above the cooling water pump casing may not be opened, whilst the generator is running. If this occurs by mistake, air will be drawn through the opening. Extensive ventilation of the whole system is then necessary.



Fig. A.16: Ventilation screw cooling water pump

#### Ventilation screw thermostat housing

The ventilation screw on the thermostat housing should occasionally be opened for control purposes. Standing machinery should principally carry out ventilating.



Fig. A.17: Ventilation screw thermostat housin

#### Water-cooled exhaust manifold

The manifold is cooled by means of the internal cooling system (freshwater). The cooling water filler necks on the casing of the manifold may not be opened. These cooling water necks are only required to fill the motor with cooling water in cases of repair. The normal cooling water controls may only be carried out at the external expansion tank.





Fig. A.18: Water-cooled exhaust manifold


## A.2.4 Components of the fuel system



**External fuel pump**

The Panda generator is always supplied with an external, electrical (12 V of DC) fuel pump. The fuel pump must be always installed in the proximity of the tank. The electrical connections with the lead planned for it are before-installed at the generator. Since the suction height and the supply pressure are limited, it can be sometimes possible that for reinforcement a second pump must be installed.


Fig. A.19: External fuel pump



**Connecting pieces for the fuel pipe**

1. Fuel intake
2. Fuel backflow

Fig. A.20: Fuel connections



**Fuel filter**

A consequential filtering of fuel is especially important for all marine systems. A fine filter, which is firmly attached to the inside of the sound insulation capsule for the marine version, is supplied on delivery, and loose for other makes. In all cases a further pre-filter with water separator must be installed. See directions for fuel filter installation.

Fig. A.21: Fuel filter

### Fuel solenoid valve

The fuel solenoid valve opens automatically if „START“ is pressed on the remote control panel“. The solenoid closes, if the generator is switched to „OFF“ position. It takes a few seconds before the generator stops. If the generator does not start or does not run smoothly (i.e. stutters), or does not attain full speed, then the cause is fore-mostly the solenoid.

- 1) Fuel solenoid valve
- 2) Ventilation screw solenoid valve
- 3) Magnetic coil




Fig. A.22: Fuel solenoid valve

### Injection nozzles

If the engine does not start after the ventilation, the fuel injection lines must be de-aerated individually.




Fig. A.23: Injection nozzles

### Glow plugs

The glow plugs serve the pre-chamber for the heating with cold start. The heat-treat fixture must be operated, if the temperature of the generator is under 16°C. This is practically with each start the case. The heat-treat fixture may be held down also during start and favoured the starting procedure.






Fig. A.24: Glow plugs


**Stop solenoid for engine stop**

Some model are additional equipped with an stop solenoid. The generator is stopped by the co-operation of the stop solenoid immediately after switching off. The adjustment of the stop solenoid must always be checked, in order to be sure that the stop lever can move also during the operation freely and is not under pre-pressing.


Fig. A.25: Stop solenoid

**A.2.5 Components of combustion air**

**Air suction openings at the sound cover**

The sound cover for the marine generator is normally provided at the lower surface with drillings, through which the combustion air can influx.

It must be consistently paid attention that the generator is installed in such a way that from down no water can arrive into the proximity of these air openings. (minimum distance 150 mm)

Fig. A.26: Combustion air intake


**Drillings for combustion air at the sound cover**

Drillings at the lower surface of the sound cover serve the admission of fresh air for the entrance. It must be safe that no raw water or other water can come into this range of this openings. If air is sucked in through these openings, water can penetrate also into the sound cover.

Fig. A.27: Sound cover drillings



### Air suction housing with 12V DC charge control

The shown air suction housing shows the 12V DC charge control (pos. 2) at the exterior. This charge control is to be checked, if the 12V DC voltage is not correct.

If the cover (pos. 1) is removed, the inside of the air suction housing becomes visible. In these air suction housings is a filter element. At the marine version the filter is normally not changed. It should be checked once in a while.




Fig. A.28: Air suction housing

### Air suction housing with air filter set

The figure shows the air filter element in the air suction housing. However the return pipe of the crank case exhaust flows also into the air suction housing, it can be faced with older generators and/or with engines on high running time that oil vapors affect the air filter. Therefore an check is advisable once in a while.




Fig. A.29: Air filter set

### Combustion chamber intake elbow

The figure shows the induction elbow at the combustion engine. At the front of this induction elbow you can see the hose connection between air suction housings and induction elbow. The air filter must be checked, if this hose pulls together at operation.




Fig. A.30: Combustion chamber intake elbow




Fig. A.31: Exhaust elbow




Fig. A.32: Exhaust connection




Fig. A.33: Exhaust outlet

## A.2.6 Components of the electrical system

### Passage for cable starter battery

1. Passage for cable starter battery (plus)
2. Passage for cable starter battery (minus)

During the connection to the starter battery it must be always ensured that the contact is perfectly guaranteed.




Fig. A.34: Passage for cable starter battery

### Connection starter battery plus cable

The plus cable of the starter battery must be connected at the solenoid of the stater motor.




Fig. A.35: Connection starter battery plus cable

### Connection starter battery minus cable

The minus cable of the starter battery must be connected at the right engine bracket when you look from the front side.



Fig. A.36: Connection starter battery minus cable




Fig. A.37: Passage for load and remote control panel




Fig. A.38: Terminal block 120V/60Hz




Fig. A.39: Terminal block 230V/50Hz

**Panel interface (on VCS)**




Fig. A.40: Panel interface (on VCS)

**Connection external fuel pump and fuel level sensor**

At the front of the sound cover is the withdrawal for the cable for the fuel pump and the fuel level sensor.

1. Cable for fuel pump
2. Cable for fuel level sensor




Fig. A.41: Fuel pump and fuel level sensor cable

**Starter motor**

1. Starter motor and
2. Solenoid switch

The Diesel engine is electrically started. On the back of the engine is accordingly the electrical starter with the solenoid switch.






Fig. A.42: Starter motor



**Actuator for speed regulation**

The generator voltage is determined by progressive speed control through "VCS" in conjunction with the speed actuator. Speed increases with increasing load.

Fig. A.43: Actuator




**DC-alternator**

All Panda generators from Panda 6.000 are provided with its own charge system for the 12V DC mains. This DC-alternator is powered over a v-belt together with the internal cooling water pump.

The 12V charge system may be used only for the generator-own starter battery.

Fig. A.44: DC-alternator



**Charge control for DC-alternator**

The voltage regulator for the 12V DC-alternator is on the back of the air suction housing. The housing is formed for cooling purposes. The voltage regulator may not be covered from the outside. The surface must be accessible for the cooling.

Fig. A.45: Charge control

**Generator power terminal box 120V/60Hz**

At the back of the generator is the generator power terminal box. In this box the electrical connection points of the AC generator are connected. Here is also the bridge for the protective grounding of the generator. The cover may only be removed, if it is guaranteed that the generator cannot be inadvertently started.



Fig. A.46: Generator power terminal box 120V/60Hz

**Generator power terminal box 230V/50Hz**

At the back of the generator is the generator power terminal box. In this box the electrical connection points of the AC generator are connected. Here is also the bridge for the protective grounding of the generator. The cover may only be removed, if it is guaranteed that the generator cannot be inadvertently started.




Fig. A.47: Generator power terminal box 230V/50Hz

**Relays**

- K0 power relay for ground isolate relay
- K1 power relay for starter motor
- K2 power relay for glow plugs
- K2.1 power relay for glow plugs
- K3 power relay for fuel pump
- K4 power relay for stop solenoid




Fig. A.48: Relays




Fig. A.49: Fuses




Fig. A.50: Fuse for DC-system




Fig. A.51: VCS

**Current transformer board**




Fig. A.52: Current transformer board

**Booster capacitors 120/60Hz**

2x40 $\mu$ F



Fig. A.53: Booster capacitors 120V/60Hz

**Booster capacitor 230/50Hz**

1x60 $\mu$ F



Fig. A.54: Booster capacitor 230V/50Hz




Fig. A.55: Excitation capacitors 120V/60Hz



Fig. A.56: Excitation capacitors 230V/50Hz




Fig. A.57: Solid state relays for booster capacitors 120V/60Hz

**Solid state relay for booster capacitor  
230V/50Hz**

1xSolid state relay for booster capacitor.




Fig. A.58: Solid state relay for booster capacitor 230V/50Hz

**Failure bypass switch**



Fig. A.59: Failure bypass switch

**A.2.7 Sensors and switches for operating surveillance**




**Thermo-switch at cylinder head**

The thermo-switch at the cylinder head serves the monitoring of the generator temperature. All thermo-switches for the generators from Panda 6.000 upward are two-pole and laid out as "openers".

110°C and 130°C

Fig. A.60: Thermo-switch at cylinder head




**Thermo-switch in the generator coil**

1. Generator coil
2. Thermo-switch 4x165/175°C
3. Housing

For the protection of the generator coil there are two thermo-switches inside the coil, which are for inserted parallel and safety's sake independently from each other.

Fig. A.61: Coil thermo-switch



**Thermo-switch at the front plate**

The generator bearing is equipped with an thermostat, which switches the engine off if the temperature becomes to high.

130°C

Fig. A.62: Thermo-switch at front plate

**Thermo-switch at water-cooled exhaust elbow**

120°C/105°C at 120V/60Hz

105°C/90°C at 230V/50Hz




Fig. A.63: Thermo-switch at exhaust elbow

**Thermo-sensor raw water in**



Fig. A.64: Thermo-sensor raw water in

**Thermo-sensor raw water out**



Fig. A.65: Thermo-sensor raw water out




Fig. A.66: Thermo-sensor raw water out




Fig. A.67: Thermo-sensor fresh water in




Fig. A.68: Thermo-sensor fresh water out

**Thermo-sensor oil temperature**



Fig. A.69: Thermo-sensor oil temperature


**Oil pressure switch**

In order to be able to monitor the lubricating oil system, an oil pressure switch is built into the system. The oil pressure switch is on the back of the engine (below the oil filter).



Fig. A.70: Oil pressure switch

## A.2.8 Components of the oil circuit




### Oil filler neck with cap

Normally the filler neck for the engine oil is on the top side of the valve cover. At numerous generator types a second filler neck is attached additionally at the operating side. Please pay attention that the filler necks are always well locked after filling in engine oil.

Consider also the references to the engine oil specification.


Fig. A.71: Oil filler neck with cap



### Oil dipstick

At the dipstick the permissible level is indicated by the markings "maximum" and "minimum". The engine oil should be never filled up beyond the maximum conditions.

Fig. A.72: Oil dipstick



### Oil filter

The oil filter should be exchanged with an oil change.

Fig. A.73: Oil filter

**Oil drain hose**

The Panda generator is equipped that the engine oil can be drained over an drain hose. The generator should be always installed therefore that a collecting basin can be set up deeply enough. If this is not possible, an electrical oil drain pump must be installed.

Note: Lubricating oil should be drained in the warm condition!




Fig. A.74: Oil drain hose

## A.3 Operation instructions

### A.3.1 Preliminary remark

**Tips regarding Starter Battery**

Fischer Panda recommends normal starter battery use. If a genset is required for extreme winter conditions, then the starter battery capacity should be doubled. It is recommended that the starter battery be regularly charged by a suitable battery-charging device (i.e., at least every 2 Months). A correctly charged starter battery is necessary for low temperatures.

### A.3.2 Daily routine checks before starting

#### 1. Oil Level Control (ideal level: MAX).

##### ATTENTION! OIL PRESSURE CONTROL!

True, the diesel motor automatically switches off when there is a lack of oil, but it is very damaging for the motor, if the oil level drops to the lowest limit. Air can be sucked in suddenly when the boat rocks in heavy seas, if the oil level is at a minimum. This affects the grease in the bearings. It is therefore necessary to check the oil level daily before initially running the generator. The oil level must be topped up to the maximum level, if the level drops below the mark between maximum und minimum levels.

**The oil level of the oil cooled bearing must be checked before every start - see flow glas at the generator front cover. Service interval 1000hrs.**



#### 2. State of Cooling Water.

The external compensation tank should be filled up to a maximum of in a cold state. It is very important that large expansion area remains above the cooling water level.

#### 3. Open Sea Cock for Cooling Water Intake.

For safety reasons, the seacock must be closed after the generator has been switched off. It should be re-opened before starting the generator.

#### 4. Check Raw Water Filter.

The raw water filter must be regularly checked and cleaned. The impeller fatigue increases, if residual affects the raw water intake.

#### 5. Check all Hose Connections and Hose Clamps are Leakage.

Leaks at hose connections must be immediately repaired, especially the raw water impeller pump. It is certainly possible that the raw water impeller pump will produce leaks, depending upon the situation. (This can be caused by sand particles in the raw water etc.) In this case, immediately exchange the pump, because the dripping water will be sprayed by the belt pulley into the sound insulated casing and can quickly cause corrosion.

#### 6. Check all electrical Lead Terminal Contacts are Firm.

This is especially the case with the temperature switch contacts, which automatically switch off the generator in case of faults. There is only safety if these systems are regularly checked, and these systems will protect the generator, when there is a fault.

#### 7. Check the Motor and Generator Mounting Screws are Tight.

The mounting screws must be checked regularly to ensure the generator is safe. A visual check of these screws must be made, when the oil level is checked.

#### 8. Switch the Land Electricity/Generator Switch to Zero before Starting or Switch Off all the load.

The generator should only be started when all the load have been switched off. The excitation of the generator will be suppressed, if the generator is switched off with load connected, left for a while, or switched on with extra load, thus reducing the residual magnetism necessary for excitation of the generator to a minimum. In certain circumstances, this can lead to the generator being re-excited by means of a DC source. If the generator does not excite itself when starting, then excitation by means of DC must be carried out again.

#### 9. Check the Automatic Controls Functions and Oil Pressure.

Removing a cable end from the monitoring switch carries out this control test. The generator should then automatically switch off. Please adhere to the inspection timetable (see Checklist in the appendix).

### A.3.3 Starting Generator

1. If necessary, open the fuel valve.
2. If necessary, close the main battery switch.
3. Check if all the load have been switched off.
The load is switched off, before the generator is switched off. The generator is not to be started with load connected. If necessary, the main switch or fuse should be switched off or the load should be individually switched off.
4. Press Standby „ON/OFF“ button (Position 2 on control panel).
Control light for "Stand by" button must light up.
5. Press Generator "RUN/STOP" button (Position 06 on control panel).
After the automatic pre-glow phase the engine starts. Control light for „Generator“ button must light up. If the genset does not immediately start, then the fuel intake should be checked to ensure it is flowing freely. (For temperatures below - 8°C check whether there is winter fuel)
6. Check circuit-voltmeter and frequency is within the tolerance rage
7. Switch on load.

### A.3.4 Stopping the Generator

1. Switch off load.
2. If the load is higher than 70% of the nominal load, the generator temperatures should be stabilised by switching off the load for at least 5 minutes.
At higher ambient temperatures (more than 25°C) the generator should always run for at least 5 minutes without load, before it is switched off, regardless of the load.
3. Press Generator „RUN/STOP“ button and switch off the generator.
4. Press Standby „ON/OFF“ button to switch off the panel.
5. Activate additional switches (Battery switch, fuel stop valve etc.).
<b>NOTE: Never switch off the battery until the generator has stopped.</b>
6. If necessary, close sea cock.



## B. Remote control panel

The remote control panel is equipped with some monitoring functions, which increases the operational safety of the generator. A failure message is shown over contacts which are normally closed. If a connection is intermitted triggers this a failure message.

### There are two different displays:

- 1) The „Engine view“, which shows you the engine relevant datas like temperatures.
- 2) The „Generator view“, which shows you the generator relevant datas like voltages.

### To Start the Engine:

- 1.) Press the „Standby“-Switch (02) - the LED below the button has to come up.


You should see a display that looks like the one beneath.

- 2.) Press the „run/stop“ button (06) (after the automatic pre-glow phase the engines starts)

The LED below the button blinks during the start procedure, when the engine has started the LED flashes constant.

First the generator runs in idle-speed for the predefined period.

Than the engine runs up to the normal rotation speed.



01. Digital display

02. S1 Button „ON/OFF“ „Stand by“

03. S2 Button alarm mute / program level

04. S3 Button display shift

05. S4 Button rpm shift / cold start

06. S5 Button run/stop / select save

**Panel „Engine view“ in Stand by mode**

T01-CH: 89°F	⌚ 00254.3h	T14-AB: 89°F
T03-EM: 68°F	0rpm	T12-C3: 66°F
T07-FWI: 91°F	0.0kW	Fuel: --- gal
T08-FWO: 66°F	0.0kVA	P01-OP: 0.0 PSI
T09-L0: 68°F		
L.O. prss. switch P09		

T01-CH: Cylinder head  
 T02-EM: Exhaust manifold  
 T07-FWI: Freshwater - in  
 T08-FWO: Freshwater - out  
 T09-LO: Lubricating oil  
 T14-AB: Alternator bearing  
 T12-C3: Temperatur at coil 3  
 (display changes - only the coil with the the highest temperature)  
 P01-OP: Oil-pressure  
 „- - -“ means that the sensor isn't connected or a cable is broken.

**Panel „Generator view“ in Stand by mode**

01	02	03	04
0rpm	⌚ 00254.3h		0.0 Hz
U1: 0V	0.0kVA	I1: 0 A	
U2: 0V	▬ %	I2: 0 A	
U3: 0V	0.0KW	I3: 0 A	
PF: 1.00i	Bs: 26.5 V	C2: 0 %	
T01: 89°F		T10: 89°F	
L.O. prss. switch P02			
05		06	

01: rounds per minute  
 02: elapsed hours  
 03: apparent power  
 04: frequency 0Hz  
 05: status line(s)  
 06: effective power with bar line  
 PF: active power factor  
 Bs: battery voltage  
 C2: compensation level  
 Un: phase voltage  
 In: phase current

**Panel „Engine view“ when unit is running without load**

T01-CH: 89°F	⌚ 00254.3h	T14-AB: 91°F
T03-EM: 91°F	3529rpm	T12-C3: 98°F
T07-FWI: 68°F	0.0kW	Fuel: --- gal
T08-FWO: 95°F	0.0kVA	P01-OP: 58 PSI
T09-L0: 89°F		


After pressing start and after the automatic pre-glow phase, the generator runs in idle-speed.  
 The engine runs up to the normal rotation speed of about 3529rpm.  
 The temperatures at the different test points begin to change.  
 Oil pressure shows 58 PSI.

**Panel „Generator view“ when unit is running without load**

The rotation speed keeps constant at approx. 3500rpm

Now you can see the voltages at the separat phases.


Values for kVA and kW are 0, because the generator runs without load.



**Panel „Engine view“ in case of warning**

T01-CH, the cylinder head - temperature has reached 232°F. The other temperatures are inside the permissible range.

A warning „Temp. cyl head“ occurs at the lower left side of the panel.




**Panel „Engine view“ in case of error**

T01-CH, the cylinder head - temperature has reached 252°F. The other temperatures are inside the permissible range.

A warning „Temp. cyl head“ occurs at the lower left side of the panel.

Additionally, a failure comes at the lower right side.



**Panel „Engine view“ after error-caused shutdown**

T01-CH: 491°F	⌚ 00254.3h	T14-AB: 95°F
T03-EM: 122°F	0rpm	T12-C3: 106°F
T07-FWI: 68°F	0.0kW	Fuel: --- gal
T08-FWO: 491°F	0.0kVA	P01-OP: 0.0 PSI
T09-L0: 89°F		
Frequency		Voltage low
Lube oil press		Lube oil press

The engine shuts down and the two status lines show different warnings and failures.

Naturally, there aren't 491°F at the T01 or T08. This value says that the temperature is too high and the engine has shut down.

**Program mode for panel parallel switching**

**ATTENTION:** It is not allowed to program two panels at the same time. Program first one panel and then the second.

To get into the „Program mode“ press the buttons „Program Level (S2)“ and „Display shift (S3)“ at the same time.

Display:	US standard (metric)
Adress:	0 (1-7)
Nominal power:	0200 x0.1kW

In this mode you must adjust the panel for parallel switching.

To change the settings use button S3 and to scroll use button S2.

The „Display“ must be switched to „US standard“.

The first panel get the „Adress 0“.

The second panel get the „Adress 1“

To store this settings press the button „Select Save“.

An failure override button enables an immediate restart facility of the generator, should it cut out, even if this was caused by over-heating. There is normally a requirement to wait until the motor has cooled down to the correct temperature. This can last for several hours in certain circumstances, since the generator is enclosed in a sound-insulated casing, which prevents heat loss.

This period can be reduced by pushing the „Alarm Mute“ button. By pressing the button all faults are overridden for 10 seconds. When the button is pressed again during the 10 seconds, 10 seconds will be added to the remaining time. The generator can be started. The button bypasses any faults allowing the generator to run.

Before depressing the button, a manual check of the oil dipstick must be carried out to determine whether the generator has sufficient oil, as it is possible that the oil pressure switch causes the generator to cut out. If it has been ascertained that the reason for the motor cutting out is overheating and not lack of oil, the generator can be run for several minutes without load, so that the motor is cooled by the circulating coolant.

#### ATTENTION:

If the temperature is the reason for the generator cutting out when it is running under load, then an immediate check must be made to determine the cause. It could be a fault with the cooling system, one of the fans, the air-intake or a fault with the external cooling system.

Continual use of the starter-override switch should be avoided, while the generator cuts out during operation. The generator must always run without load for several minutes before being switched off, so that a temperature compensation occurs. Heat accumulation can cause the generator to overheat, even after ist has been switched off.

Should the overheating alarm be set off, caused by heat accumulation, after the generator has been switched off, then this can also be bypassed using the switch.

Push:

„Alarm Mute“ to acknowledge

again „Alarm Mute“ to deactivate all sensors and

„Motor Start“ to restart the engine

