

Raymarine



AXIOM+

Installation instructions

English (en-US)
Date: 06-2020
Document number: 87414-1
© 2020 Raymarine UK Limited

Trademark and patents notice

Raymarine, Tacktick, Clear Pulse, Truzoom, SeaTalk, SeaTalk^{hs}, SeaTalkng, and **Micronet**, are registered or claimed trademarks of Raymarine Belgium.

FLIR, LightHouse, DownVision, SideVision, RealVision, HyperVision, Dragonfly, Element, Quantum, Axiom, Instalert, Infrared Everywhere, The World's Sixth Sense and **ClearCruise** are registered or claimed trademarks of FLIR Systems, Inc.

All other trademarks, trade names, or company names referenced herein are used for identification only and are the property of their respective owners.

This product is protected by patents, design patents, patents pending, or design patents pending.

Fair Use Statement

You may print no more than three copies of this manual for your own use. You may not make any further copies or distribute or use the manual in any other way including without limitation exploiting the manual commercially or giving or selling copies to third parties.

Software updates



Check the Raymarine website for the latest software releases for your product.
www.raymarine.com/software

Product documentation



The latest versions of all English and translated documents are available to download in PDF format from the website: www.raymarine.com/manuals.
Please check the website to ensure you have the latest documentation.

Publication copyright

Copyright ©2020 Raymarine UK Ltd. All rights reserved.

Contents

Chapter 1 Important information	9
Disclaimers	9
RF exposure	9
Compliance Statement (Part 15.19)	9
FCC Interference Statement (Part 15.105 (b))	9
Innovation, Science and Economic Development Canada (ISED)	10
Innovation, Sciences et Développement économique Canada (Français)	10
Japanese approvals	10
MSIP Warning Statement for Radio Devices (Korea only)	10
Declaration of Conformity	11
Product disposal	11
Warranty registration	11
Technical accuracy	11
Chapter 2 Document and product information	13
2.1 Product documentation	14
LightHouse™ 3 MFD Operation instructions	14
2.2 Applicable products	14
Axiom™+ Multifunction Displays	14
2.3 Compatible transducers for Axiom™+ RV Multifunction displays	16
RealVision transducers	16
DownVision™ transducers	17
CHIRP conical beam transducers (using DownVision™ type connector)	17
2.4 Parts supplied - Axiom™ 7+	19
2.5 Parts Supplied - Axiom™ 7+ (DISP)	19
2.6 Parts supplied - Axiom™ 9+ and Axiom™ 12+	20
2.7 Parts supplied - Axiom™ 9+ (DISP) and Axiom™ 12+ (DISP)	21
Chapter 3 Installation	23
3.1 Selecting a location	24
General location requirements	24
EMC installation guidelines	24
RF interference	25
Compass safe distance	25
GNSS (GPS) location requirements	25
Touchscreen location requirements	27
Wireless location requirements	27
Viewing angle considerations	27
Product dimensions	28
3.2 Mounting options	30
3.3 Bracket (Trunnion) mounting	31
3.4 Axiom 7 flush and surface mounting	33

Removing the trunnion adaptor Axiom™ 7	33
Surface or Flush mounting Axiom™ 7 only.....	33
3.5 Surface or flush mounting using the Rear Mount Kit	35
Chapter 4 Connections.....	37
4.1 Connections overview	38
Connecting cables.....	38
4.2 Power connection	39
In-line fuse and thermal breaker ratings.....	39
Power distribution.....	40
Grounding — optional dedicated drain wire	44
4.3 NMEA 2000 (SeaTalkng®) connection	45
4.4 Transducer connection.....	45
RealVision™ 3D transducer extension cable	46
DownVision™ transducer extension cable	46
Axiom transducer adaptor cables.....	46
4.5 Network connection.....	47
4.6 Accessory connection	47
Chapter 5 Maintaining your display	49
5.1 Service and maintenance.....	50
Routine equipment checks	50
5.2 Product cleaning	50
Cleaning the display screen	50
Cleaning the display case.....	51
Disinfecting the display.....	51
Cleaning the sun cover.....	51
Chapter 6 Troubleshooting	53
6.1 Troubleshooting	54
6.2 LED Diagnostics	54
6.3 Power up troubleshooting.....	55
Performing a power on reset — Axiom™	55
6.4 GNSS (GPS) troubleshooting	56
6.5 Sonar troubleshooting.....	57
6.6 Wi-Fi troubleshooting	60
6.7 Touchscreen troubleshooting.....	63
6.8 Miscellaneous troubleshooting	64
Chapter 7 Technical support.....	65
7.1 Raymarine product support and servicing	66
Viewing product information (LightHouse™ 3).....	67
7.2 Learning resources	68
Chapter 8 Technical specification.....	69

8.1 Axiom+ technical specification	70
8.2 RealVision™ 3D sonar specification.....	71
8.3 Internal GNSS (GPS / GLONASS) receiver specification	71
Chapter 9 Spares and accessories	73
9.1 AXIOM accessories.....	74
Axiom transducer adaptor cables.....	74
Legacy MFD adaptor plates.....	74
9.2 AXIOM spares.....	75
9.3 RayNet to RayNet cables and connectors	76
RayNet to RJ45 adapter cables	76
9.4 SeaTalkng® cables and accessories.....	78

Chapter 1: Important information



Warning: Product installation and operation

- This product must be installed and operated in accordance with the instructions provided. Failure to do so could result in personal injury, damage to your vessel and/or poor product performance.
- Raymarine recommends certified installation by a Raymarine approved installer. A certified installation qualifies for enhanced product warranty benefits. Contact your Raymarine dealer for further details, and refer to the separate warranty document packed with your product.



Warning: High voltage

This product contains high voltage. Adjustments require specialized service procedures and tools only available to qualified service technicians. There are no user serviceable parts or adjustments. The operator should never remove the cover or attempt to service the product.

Disclaimers

Raymarine does not warrant that this product is error-free or that it is compatible with products manufactured by any person or entity other than Raymarine.

This product uses digital chart data, and electronic information from Global Navigation Satellite Systems (GNSS) which may contain errors. Raymarine does not warrant the accuracy of such information and you are advised that errors in such information may cause the product to malfunction. Raymarine is not responsible for damages or injuries caused by your use or inability to use the product, by the interaction of the product with products manufactured by others, or by errors in chart data or information utilized by the product and supplied by third parties.

This product supports electronic charts provided by third party suppliers which may be embedded or stored on memory card. Use of such charts is subject to the supplier's End-User Licence Agreement.

RF exposure

This equipment complies with FCC / ISED RF exposure limits for general population / uncontrolled exposure. The wireless LAN / Bluetooth antenna is mounted behind the front facia of the display. This equipment should be installed and operated with a minimum distance of 1 cm (0.39 in) between the device and the body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter, except in accordance with FCC multi-transmitter product procedures.

Compliance Statement (Part 15.19)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

FCC Interference Statement (Part 15.105 (b))

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular

installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio / TV technician for help.

Innovation, Science and Economic Development Canada (ISED)

This device complies with License-exempt RSS standard(s).

Operation is subject to the following two conditions:

1. This device may not cause interference; and
2. This device must accept any interference, including interference that may cause undesired operation of the device.

This Class B digital apparatus complies with Canadian ICES-003.

Innovation, Sciences et Développement économique Canada (Français)

Cet appareil est conforme aux normes d'exemption de licence RSS.

Son fonctionnement est soumis aux deux conditions suivantes:

1. cet appareil ne doit pas causer d'interférence, et
2. cet appareil doit accepter toute interférence, notamment les interférences qui peuvent affecter son fonctionnement.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Japanese approvals

In the frequency band used for this device, campus radio stations (radio stations that require a license) and specified low power radio stations (radio stations that do not require license) for mobile identification and amateur radio stations (radio stations that require license) used in industries such as microwave ovens, scientific, medical equipment devices and production line of other factories are also being operated.

1. Before using this device, please make sure that campus radio stations and specified low power radio stations for mobile identification and amateur radio stations are not being operated nearby.
2. In case there is any case of harmful interference to campus radio stations for mobile identification caused by this device, please immediately change the frequency used or stop the transmission of radio waves and then consult about the measures to avoid interference (for example, the installation of partitions) through the contact information below.
3. Besides, when in trouble, such as when there is any case of harmful interference to specified low power radio stations for mobile identification or amateur radio stations caused by this device, please consult through the following contact information.

Contact information: Please contact your local authorized Raymarine dealer.

MSIP Warning Statement for Radio Devices (Korea only)

- 제작자 및 설치자는 해당 무선설비가 전파혼신 가능성이 있으므로 안전 인명과 관련된
- 서비스는 할 수 없음을 사용자 설명서 등을 통하여 운전자 및 사용자에게 충분히 알릴 것

- 법에 의해 전 방향 전파 발사 및 동일한 정보를 동시에 여러 곳으로 송신하는 점-대-다지점 서비스에의 사용은 금지되어 있습니다.

Declaration of Conformity

FLIR Belgium BVBA declares that the products listed below are in compliance with the EMC Directive 2014/53/EU:


- Axiom™7+, part numbers E70634 and E70634–DISP
- Axiom™7+ RV, part numbers E70635, E70635–03 and E70635–DISP
- Axiom™9+, part numbers E70636 and E70636–DISP
- Axiom™9+ RV, part numbers E70637, E70637–03 and E70637–DISP
- Axiom™12+, part numbers E70638 and E70638–DISP
- Axiom™12+ RV, part numbers E70639, E70639–03 and E70639–DISP

The original Declaration of Conformity certificate may be viewed on the relevant product page at www.raymarine.com/manuals.

Product disposal

Dispose of this product in accordance with the WEEE Directive.

The Waste Electrical and Electronic Equipment (WEEE) Directive requires the recycling of waste electrical and electronic equipment which contains materials, components and substances that may be hazardous and present a risk to human health and the environment when WEEE is not handled correctly.



Equipment marked with the crossed-out wheeled bin symbol indicates that the equipment should not be disposed of in unsorted household waste. Local authorities in many regions have established collection schemes under which residents can dispose of waste electrical and electronic equipment at a recycling center or other collection point. For more information about suitable collection points for waste electrical and electronic equipment in your region, refer to the Raymarine website: www.raymarine.eu/recycling.



Warranty registration

To register your Raymarine product ownership, please visit www.raymarine.com and register online.

It is important that you register your product to receive full warranty benefits. Your unit package includes a bar code label indicating the serial number of the unit. You will need this serial number when registering your product online. You should retain the label for future reference.

Technical accuracy

To the best of our knowledge, the information in this document was correct at the time it was produced. However, Raymarine cannot accept liability for any inaccuracies or omissions it may contain. In addition, our policy of continuous product improvement may change specifications without notice. As a result, Raymarine cannot accept liability for any differences between the product and this document. Please check the Raymarine website (www.raymarine.com) to ensure you have the most up-to-date version(s) of the documentation for your product.

Chapter 2: Document and product information

Chapter contents

- 2.1 Product documentation on page 14
- 2.2 Applicable products on page 14
- 2.3 Compatible transducers for Axiom™+ RV Multifunction displays on page 16
- 2.4 Parts supplied - Axiom™ 7+ on page 19
- 2.5 Parts Supplied - Axiom™ 7+ (DISP) on page 19
- 2.6 Parts supplied - Axiom™ 9+ and Axiom™ 12+ on page 20
- 2.7 Parts supplied - Axiom™ 9+ (DISP) and Axiom™ 12+ (DISP) on page 21

2.1 Product documentation

The following documentation is applicable to your product:

All documents are available to download as PDFs from www.raymarine.com

Documentation

Description	Part number
Installation instructions (This document)	87414
Surface/Flush mounting template	• 7" — 87295 • 9" — 87296 • 12" — 87297
Front installation kit Installation instructions	87304
Legacy MFD to Axiom adaptor plates installation instructions	87316
RCR-SDUSB Installation instructions	87317
LightHouse™ 3 Basic operation instructions	81369
LightHouse™ 3 Advanced operation instructions	81370

LightHouse™ 3 MFD Operation instructions

For operation instructions for your product please refer to the LightHouse™ 3 MFD Operation instructions.



The Basic (81369) and Advanced (81370) LightHouse™ 3 Operation Instructions can be downloaded from the Raymarine website: www.raymarine.com/manuals. Please check the website to ensure you have the latest documentation.

2.2 Applicable products

This document is applicable to the following products:

Axiom™ + Multifunction Displays



Product number	Name	Description
E70634	Axiom™ 7+	7" MFD Chartplotter.
E70634-DISP	Axiom™ 7+	7" MFD Chartplotter (supplied with Rear mount kit only).
E70635	Axiom™ 7+ RV 3D	7" MFD with built-in RealVision™ 3D sonar module.
E70635-03	Axiom™ 7+ RV 3D (including RV-100 transom transducer)	7" MFD with built-in RealVision™ 3D sonar module.
E70635-DISP	Axiom™ 7+ RV 3D	7" MFD with built-in RealVision™ 3D sonar module (supplied with Rear mount kit only).
E70636	Axiom™ 9+	9" MFD Chartplotter.
E70636-DISP	Axiom™ 9+	9" MFD Chartplotter (supplied with Rear mount kit only).
E70637	Axiom™ 9+ RV 3D	9" MFD with built-in RealVision™ 3D sonar module.
E70637-03	Axiom™ 9+ RV 3D (including RV-100 transom transducer)	9" MFD with built-in RealVision™ 3D sonar module.
E70637-DISP	Axiom™ 9+ RV 3D	9" MFD with built-in RealVision™ 3D sonar module (supplied with Rear mount kit only).
E70638	Axiom™ 12+	12" MFD Chartplotter.
E70638-DISP	Axiom™ 12+	12" MFD Chartplotter (supplied with Rear mount kit only).
E70639	Axiom™ 12+ RV 3D	12" MFD with built-in RealVision™ 3D sonar module.
E70639-03	Axiom™ 12+ RV 3D (including RV-100 transom transducer)	12" MFD with built-in RealVision™ 3D sonar module.
E70639-DISP	Axiom™ 12+ RV 3D	12" MFD with built-in RealVision™ 3D sonar module (supplied with Rear mount kit only).

2.3 Compatible transducers for Axiom™ + RV Multifunction displays

Axiom™+RV variant Multifunction Displays (MFDs) include a built-in sonar module and can be connected directly to compatible transducers using the 25-pin transducer connector on the rear of the display.

Compatible transducers:


- RealVision™ 3D transducers
- DownVision™ transducers using available adaptor cables. Refer to [Chapter 9 Spares and accessories](#) for a list of available adaptor cables.
- CHIRP conical beam transducers using available adaptor cables. Refer to [Chapter 9 Spares and accessories](#) for a list of available adaptor cables.
- Non-CHIRP transducer can be connected using available adaptor cables. Refer to [Chapter 9 Spares and accessories](#) for a list of available adaptor cables. Refer to the Raymarine® website for compatible transducers: www.raymarine.com/transducers.

Note:

Chartplotter only variant Axiom™+ MFDs require a networked sonar module to enable sonar features.

RealVision transducers

The transducers listed below can be connected directly to RealVision™ 3D variant MFDs.




1	• RV-100 RealVision™ 3D plastic transom mount transducer (A80464)
2	• RV-200 RealVision™ 3D bronze 0° thru-hull all-in-one transducer (A80465) • RV-212P and RV-212S RealVision™ 3D bronze 12° thru-hull split-pair transducers (T70318) – RV-212P port transducer (A80466) – RV-212S starboard transducer (A80467) • RV-220P and RV-220S RealVision™ 3D bronze 20° thru-hull split-pair transducers (T70319) – RV-220P port transducer (A80468) – RV-220S starboard transducer (A80469)
3	• RV-300 RealVision™ 3D plastic 0° thru-hull all-in-one transducer (A80470) • RV-312P and RV-312S RealVision™ 3D plastic 12° thru-hull split-pair transducers (T70320) – RV-312P port transducer (A80471) – RV-312S starboard transducer (A80472) • RV-320P and RV-320S RealVision™ 3D plastic 20° thru-hull split-pair transducers (T70321) – RV-320P port transducer (A80473)

	– RV-320S starboard transducer (A80474)
4	• RV-400 RealVision™ 3D stainless steel 0° thru-hull all-in-one transducer (A80615) • RV-412P and RV-412S RealVision™ 3D stainless steel 12° thru-hull split-pair transducers (T70450) – RV-412P port transducer (A80616) – RV-412S starboard transducer (A80617) • RV-420P and RV-420S RealVision™ 3D stainless steel 20° thru-hull split-pair transducer (T70451) – RV-420P port transducer (A80618) – RV-420S starboard transducer (A80619)

DownVision™ transducers

The DownVision™ transducers shown below can be connected using adaptor cable A80490.




1	CPT-100DVS plastic transom mount transducer (A80351) (replaces CPT-100 A80270)
2	CPT-110 plastic thru-hull transducer (A80277)
3	CPT-120 bronze thru-hull transducer (A80271)

CHIRP conical beam transducers (using DownVision™ type connector)

The transducers shown below can be connected using adaptor cable A80490.

CPT-S transducers use CHIRP sonar technology to produce a conical-shaped sonar beam.

Note: CPT-S transducers do NOT offer DownVision™ or RealVision™ channels.




1	• CPT-S plastic transom transducer (E70342)
2	• CPT-S plastic thru-hull 0° angled element (E70339) • CPT-S plastic thru-hull 12° angled element (A80448) • CPT-S plastic thru-hull 20° angled element (A80447)
3	• CPT-S bronze thru-hull 0° angled element (A80446) • CPT-S bronze thru-hull 12° angled element (E70340) • CPT-S bronze thru-hull 20° angled element (E70341)

2.4 Parts supplied - Axiom™ 7+

The parts listed are supplied with the following product numbers: E70634 and E70635.

Unpack your product carefully to prevent damage or loss of parts. Check the box contents against the list below. Retain the packaging and documentation for future reference.




1. MFD (supplied with Trunnion adaptor fitted)
 2. Trunnion bracket
 3. Trunnion knobs x 2
 4. Suncover — Trunnion mount
 5. Panel mount gasket for surface/flush mounting
 6. M5x58 Threaded studs x 4
 7. M5 Thumb nuts x 4
 8. Documentation pack
 9. DeviceNet to SeaTalkng® adaptor cable 120 mm (4.7 in)
 10. Power/NMEA 2000 cable (with 1.5 m (4.92 ft) power lead and 0.5 m (1.64 ft) NMEA 2000 lead).
- E70635–03 is also supplied with a RealVision™ 3D RV-100 transducer and associated fittings.

2.5 Parts Supplied - Axiom™ 7+ (DISP)

The parts listed are supplied with the following product numbers: E70634–DISP and E70635–DISP.

Unpack your product carefully to prevent damage or loss of parts. Check the box contents against the list below. Retain the packaging and documentation for future reference.




1. MFD
2. Rear mount brackets x 2
3. Suncover — Surface mount
4. Panel mount gasket for surface/flush mounting
5. M5x58 Threaded studs x 4
6. M5 Thumb nuts x 4
7. Documentation pack
8. DeviceNet to SeaTalkng® adaptor cable 120 mm (4.7 in)
9. Power/NMEA 2000 cable (with 1.5 m (4.92 ft) power lead and 0.5 m (1.64 ft) NMEA 2000 lead).

2.6 Parts supplied - Axiom™ 9+ and Axiom™ 12+

The parts listed are supplied with the following product numbers: E70636, E70637, E70638 and E70639.

Unpack your product carefully to prevent damage or loss of parts. Check the box contents against the list below. Retain the packaging and documentation for future reference.




1. MFD
 2. Trunnion bracket
 3. Trunnion knobs x 2
 4. Suncover
 5. Panel mount gasket for surface/flush mounting
 6. Rear mounting brackets:
 - a. supplied with 9" MFD
 - b. supplied with 12" MFD
 7. Documentation pack
 8. M5x58 Threaded studs x 4
 9. M5 Thumb nuts x 4
 10. DeviceNet to SeaTalkng[®] adaptor cable 120 mm (4.7 in)
 11. Power/NMEA 2000 cable (with 1.5 m (4.92 ft) power lead and 0.5 m (1.64 ft) NMEA 2000 lead).
- E70637-03 is also supplied with a RealVision[™] 3D RV-100 transducer and associated fittings.
 E70639-03 is also supplied with a RealVision[™] 3D RV-100 transducer and associated fittings.

2.7 Parts supplied - Axiom[™] 9+ (DISP) and Axiom[™] 12+ (DISP)

The parts listed are supplied with the following product numbers: E70636-DISP, E70637-DISP, E70638-DISP and E70639-DISP.

Unpack your product carefully to prevent damage or loss of parts. Check the box contents against the list below. Retain the packaging and documentation for future reference.



1. MFD
2. Panel mount gasket for surface/flush mounting
3. Suncover
4. DeviceNet to SeaTalkng[®] adaptor cable 120 mm (4.7 in)
5. M5x58 Threaded studs x 4
6. Rear mounting brackets:
 - a. supplied with 9" MFD
 - b. supplied with 12" MFD
7. Documentation pack
8. M5 Thumb nuts x 4
9. Power/NMEA 2000 cable (with 1.5 m (4.92 ft) power lead and 0.5 m (1.64 ft) NMEA 2000 lead).

Chapter 3: Installation

Chapter contents

- 3.1 Selecting a location on page 24
- 3.2 Mounting options on page 30
- 3.3 Bracket (Trunnion) mounting on page 31
- 3.4 Axiom 7 flush and surface mounting on page 33
- 3.5 Surface or flush mounting using the Rear Mount Kit on page 35

3.1 Selecting a location

Caution: Product weight

- Refer to the technical specification for your product to ensure the intended mounting surface is suitable to bear its weight.
- 2 people may be required for installation of larger / heavier products.



Warning: Switch off power supply

Ensure the vessel's power supply is switched OFF before starting to install this product. Do NOT connect or disconnect equipment with the power switched on, unless instructed in this document.



Warning: Potential ignition source

This product is NOT approved for use in hazardous/flammable atmospheres. Do NOT install in a hazardous/flammable atmosphere (such as in an engine room or near fuel tanks).

General location requirements

When selecting a location for your product it is important to consider a number of factors.

Key factors which can affect product performance are:

- **Ventilation** — To ensure adequate airflow:
 - Ensure that product is mounted in a compartment of suitable size.
 - Ensure that ventilation holes are not obstructed. Allow adequate separation of all equipment.Any specific requirements for each system component are provided later in this chapter.
- **Mounting surface** — Ensure product is adequately supported on a secure surface. Do not mount units or cut holes in places which may damage the structure of the vessel.
- **Cabling** — Ensure the product is mounted in a location which allows proper routing, support and connection of cables:
 - Minimum bend radius of 100 mm (3.94 in) unless otherwise stated.
 - Use cable clips to prevent stress on connectors.
 - If your installation requires multiple ferrites to be added to a cable then additional cable clips should be used to ensure the extra weight of the cable is supported.
- **Water ingress** — The product is suitable for mounting both above and below decks. Although the unit is waterproof, it is good practice to locate it in a protected area away from prolonged and direct exposure to rain and salt spray.
- **Electrical interference** — Select a location that is far enough away from devices that may cause interference, such as motors, generators and radio transmitters / receivers.
- **Power supply** — Select a location that is as close as possible to the vessel's DC power source. This will help to keep cable runs to a minimum.

EMC installation guidelines

Raymarine equipment and accessories conform to the appropriate Electromagnetic Compatibility (EMC) regulations, to minimize electromagnetic interference between equipment and minimize the effect such interference could have on the performance of your system

Correct installation is required to ensure that EMC performance is not compromised.

Note: In areas of extreme EMC interference, some slight interference may be noticed on the product. Where this occurs the product and the source of the interference should be separated by a greater distance.

For **optimum** EMC performance we recommend that wherever possible:

- Raymarine equipment and cables connected to it are:

- At least 1 m (3.3 ft) from any equipment transmitting or cables carrying radio signals e.g. VHF radios, cables and antennas. In the case of SSB radios, the distance should be increased to 2 m (6.6 ft).
- More than 2 m (6.6 ft) from the path of a radar beam. A radar beam can normally be assumed to spread 20 degrees above and below the radiating element.
- The product is supplied from a separate battery from that used for engine start. This is important to prevent erratic behavior and data loss which can occur if the engine start does not have a separate battery.
- Raymarine specified cables are used.
- Cables are not cut or extended, unless doing so is detailed in the installation manual.

Note:

Where constraints on the installation prevent any of the above recommendations, always ensure the maximum possible separation between different items of electrical equipment, to provide the best conditions for EMC performance throughout the installation.

RF interference

Certain third-party external electrical equipment can cause Radio Frequency (RF) interference with GNSS (GPS), AIS or VHF devices, if the external equipment is not adequately insulated and emits excessive levels of electromagnetic interference (EMI).

Some common examples of such external equipment include LED lighting (e.g.: navigation lights, searchlights and floodlights, interior and exterior lights) and terrestrial TV tuners.

To minimize interference from such equipment:

- Keep it as far away from GNSS (GPS), AIS or VHF products and their antennas as possible.
- Ensure that any power cables for external equipment are not entangled with the power or data cables for these devices.
- Consider fitting one or more high frequency suppression ferrites to the EMI-emitting device. The ferrite(s) should be rated to be effective in the range 100 MHz to 2.5 GHz, and should be fitted to the power cable and any other cables exiting the EMI-emitting device, as close as possible to the position where the cable exits the device.

Compass safe distance

To prevent potential interference with the vessel's magnetic compasses, ensure an adequate distance is maintained from the product.


When choosing a suitable location for the product you should aim to maintain the maximum possible distance from any compasses. Typically this distance should be at least 1 m (3.3 ft) in all directions. However for some smaller vessels it may not be possible to locate the product this far away from a compass. In this situation, when choosing the installation location for your product, ensure that the compass is not affected by the product when it is in a powered state.

GNSS (GPS) location requirements

In addition to general guidelines concerning the location of marine electronics, there are a number of environmental factors to consider when installing equipment with an internal GNSS receiver.

Mounting location

- Above Decks (e.g. open air) mounting: Provides optimal performance. (For equipment with appropriate waterproof rating.)
- Below Decks (e.g. enclosed space) mounting: Performance may be less effective and may require an external antenna or receiver mounted above decks.



1		This location provides optimal performance (above decks).
2		In this location, performance may be less effective.
3		This location is NOT recommended.

Vessel construction

The construction of your vessel can have an impact on performance. For example, the proximity of heavy structures such as a structural bulkhead, or the interior of larger vessels may result in a reduced signal. The construction materials can also have an impact. In particular, steel, aluminium or carbon surfaces can impact performance. Before locating equipment with an internal antenna below decks, or on a steel, aluminium or carbon construction vessel or surface, seek professional assistance.

Prevailing conditions

The weather and location of the vessel can affect performance. Typically calm clear conditions provide a more accurate position fix. Vessels at extreme northerly or southerly latitudes may also receive a weaker signal. An antenna mounted below decks will be more susceptible to performance issues related to the prevailing conditions.

Touchscreen location requirements

Note:

Touchscreen performance can be affected by the installation environment, specifically Touchscreen displays installed above decks, where it will be open to the elements may exhibit the following:

- Hot Touchscreen temperature — If the display is mounted where it will be exposed to prolonged periods of direct sunlight, the touchscreen may become hot.
- Erroneous Touchscreen performance — Exposure to prolonged rain and / or water wash over may cause the display to respond to 'false touches', caused by the rain/water hitting the screen.

If, due to the required installation location, exposure to these elements is anticipated then it is recommended that you consider:

- Installing a remote keypad such as the RMK-10 and operating the display remotely — Touch-only displays.
- Locking the Touchscreen and using the physical buttons instead — HybridTouch displays.
- Attaching a third-party 'display hood accessory' to reduce direct sunlight exposure and the volume of water that the display is exposed to.

Wireless location requirements

A number of factors can influence wireless performance. It is important to ensure you test the connection performance at the desired location before installing wireless-enabled products.

Distance

The distance between wireless products should always be kept to a minimum. Do not exceed the maximum stated range of your wireless product (maximum range will vary for each device).

Wireless performance degrades over distance, so products farther away will receive less network bandwidth. Products installed close to their maximum wireless range may experience slow connection speeds, signal dropouts, or not being able to connect at all.

Line of sight

For best results the wireless product should have a clear, direct line of sight to the product it will be connected to. Any physical obstructions can degrade or even block the wireless signal.

The construction of your vessel can also have an impact on wireless performance. For example, metal structural bulkheads and roofing will reduce — and in certain situations — block the wireless signal.

If the wireless signal passes through a bulkhead containing power cables this can also degrade wireless performance.

Reflective surfaces such as metal surfaces, some types of glass and even mirrors can drastically affect performance or even block the wireless signal.

Interference and other equipment

Wireless products should be installed at least 1m (3 ft) away from:

- Other wireless-enabled products.
- Transmitting products that send wireless signals in the same frequency range.
- Other electrical, electronic or electromagnetic equipment that may generate interference.

Interference from other people's wireless devices can also cause interference with your products. You can use a third-party wireless analyzer tool / smartphone app to assess the best wireless channel to use (e.g. a channel not in use or one used by the least number of devices).


Viewing angle considerations

As display contrast and color are affected by the viewing angle, It is recommended that you temporarily power up the display, prior to installation, to enable you to best judge which location provides the optimum viewing angle.

For the viewing angles for your product refer to [p.69 — Technical specification](#)

Product dimensions


Axiom 7 trunnion mount dimensions




A	250.4 mm (9.86 in)
B	162.5 mm (6.4 in)
C	76.4 mm (3 in)
D	• Straight connectors = 218 mm (8.58 in) • Right-angled connectors = 198 mm (7.79 in)

Axiom 7 surface and flush mount dimensions

Using adaptor bracket




Using Rear mount kit




A	201.1 mm (7.92 in)
B	133 mm (5.24 in)
C	8 mm (0.32 in)
D	• Surface mounting = 19.05 mm (0.75 in) Maximum • Flush mounting = 27.05 mm (1.06 in) Maximum
E	• Straight connectors = 218 mm (8.58 in) • Right-angled connectors = 198 mm (7.79 in)
F	73 mm (2.87 in)
G	132 mm (5.2 in)

Axiom 9 and 12 trunnion mount dimensions



	Axiom™ 9	Axiom™ 12
A	265.03 mm (10.43 in)	314 mm (12.36 in)
B	187.81 (7.39 in)	226.72 mm (8.93 in)
C	76.71 mm (3.02 in)	76.2 mm (3 in)
D	65 mm (2.56 in)	65 mm (2.56 in)
E	• Straight connectors = 178 mm (7.01 in) • Right-angled connectors = 158 mm (6.22 in)	• Straight connectors = 178 mm (7.01 in) • Right-angled connectors = 158 mm (6.22 in)

Axiom 9 and 12 surface and flush mount dimensions




	Axiom™ 9	Axiom™ 12
A	244.08 mm (9.64 in)	314 mm (12.36 in)
B	157.78 mm (6.21 in)	217 mm (8.54 in)
C	8 mm (0.31 in)	
D	27.05 mm (1.06 in) Maximum	
E	157 mm 6.18 in	222 mm (8.74 in)
F	178 mm (7.01 in)	
G	19.05 mm (0.75 in) Maximum	

Note:

The rear mount brackets shown in the illustration are supplied with the Axiom™ 9, The brackets supplied with the Axiom™ 12 look different.

3.2 Mounting options

Your product can be mounted in various ways to suit any installation requirements.




1. Trunnion mount
2. Flush mount (Mounting surface and MFD screen a level)
3. Surface mount (MFD screen protrudes slightly from mounting surface)
4. Front mount (using the Front Installation Kit accessory: 7": A80498, 9": A80500, 12": A80502)

Legacy MFD adaptor plates are also available to enable you to easily swap out older MFDs for new Axiom MFDs, please refer to [Chapter 9 Spares and accessories](#) for a list of available adaptors.

3.3 Bracket (Trunnion) mounting

The bracket can be used to mount your MFD on a horizontal surface, the bracket can also be used to mount the MFD in an above head installation.

Ensure you have chosen a suitable mounting location for your MFD, with sufficient head room to allow the MFD's angle to be adjusted or the MFD to be removed if necessary. If installing 'above head' take extra care to ensure the knobs are tightened sufficiently to prevent them coming undone due to vibration when underway.



Note: The illustration depicts an Axiom™ 7 being mounted on a plastic trunnion bracket. The trunnion bracket supplied with the Axiom™ 9 and Axiom™ 12 are made from metal and so look different than the trunnion shown. A metal trunnion bracket is also available for the Axiom™ 7 as an accessory; Part number: R70524.

1. Using the Bracket as a template, Mark and drill 4 x pilot holes on the mounting surface.
2. Use self tapping screws to secure the trunnion bracket to the mounting surface.

If the mounting surface is too thin for the screws provided, use stainless steel machine screws, washers and locking nuts, alternatively reinforce the rear of the mounting surface.

3. Using the bracket knobs, secure the MFD to the Bracket, ensuring the ratchet teeth are correctly engaged.


The knobs should be tightened by hand, sufficiently to prevent the MFD from moving whilst your vessel is underway.

4. Route and connect necessary cables.

3.4 Axiom 7 flush and surface mounting

Removing the trunnion adaptor Axiom™ 7

The trunnion adaptor supplied fitted to the Axiom™ 7 can be removed to enable the adaptor to be used as a clamp for surface and flush mount installations, the adaptor must also be removed before installation the unit using the Rear mount brackets or Front Installation kit.




1. Unscrew the 4 x M5x16 screws using a 4 mm hex wrench (Allen key).
2. Pull the trunnion adaptor away from the MFD.

Surface or Flush mounting Axiom™ 7 only

When suitable access is available behind the desired mounting surface, the MFD can be surface or flush mounted.

First, ensure you have removed the Trunnion adaptor from the rear of the MFD.



1. Using the Surface/Flush mounting template as a guide, cut the relevant cut out hole in the mounting surface, if you are Flush mounting the MFD, also follow the rebate information on the mounting template.
2. Screw the 4 x studs into the rear of the MFD.
3. Remove the backing from the gasket and attach it to the rear of the MFD, ensuring that the black, soft side is against the rear of the MFD.
4. Insert the MFD into the cut out hole.

Important: In above decks, flush mount installations, marine grade silicone should be used to seal the gap between the edge of the mounting surface and the edge of the MFD.

5. Place the Trunnion adaptor over the back of the MFD.
6. Secure the MFD in position by hand-tightening the thumb nuts onto the studs.

Important: To prevent potential damage to the unit, do NOT overtighten the thumb nuts. Hand tighten only.


7. If required insert your MicroSD card into the MFD card reader, located behind the rubber bung on the rear of the MFD.
8. Route and connect necessary cables.

Note: The suncover provided in the box is for use in Trunnion bracket installations, when Surface mounting the product accessory suncover R70527 is required. No suncover is available for Flush mount installations.

3.5 Surface or flush mounting using the Rear Mount Kit

When suitable access is available behind the desired mounting surface then the MFD can be surface or flush mounted using the Rear Mount Kit.

For Axiom™ 7 MFD, supplied with the trunnion adaptor fitted, first remove the Trunnion adaptor from the rear of the MFD.




1. Using the Surface/Flush mounting template as a guide, cut the relevant cut out hole in the mounting surface, if you are Flush mounting the MFD, also follow the rebate information on the mounting template.
2. Screw the 4 x studs into the rear of the MFD.
3. Remove the backing from the gasket and attach it to the rear of the MFD, ensuring that the black, soft side is against the rear of the MFD.
4. Insert the MFD into the cut out hole.


Important: In above decks, flush mount installations, marine grade silicone should be used to seal the gap between the edge of the mounting surface and the edge of the MFD.

5. Place the Rear Mount Brackets over the studs.


Depending on the size of your MFD, the brackets will look different, however the installation procedure remains the same.



Axiom™ 7



Axiom™ 9



Axiom™ 12

6. Secure the MFD in position by hand-tightening the thumb nuts onto the studs.

Important: To prevent potential damage to the unit, do NOT overtighten the thumb nuts. Hand tighten only.

7. If required insert your MicroSD card into the MFD card reader located behind the rubber bung on the rear of the MFD.
8. Route and connect necessary cables.


Chapter 4: Connections

Chapter contents


- 4.1 Connections overview on page 38
- 4.2 Power connection on page 39
- 4.3 NMEA 2000 (SeaTalkng[®]) connection on page 45
- 4.4 Transducer connection on page 45
- 4.5 Network connection on page 47
- 4.6 Accessory connection on page 47

4.1 Connections overview

Axiom™+ rear view



Axiom™+ connectors



1. Network connection — Connects to RayNet network or device. Refer to [p.73 — Spares and Accessories](#) for available cables.
2. Accessory connection — Connects to Remote Card Reader (RCR) accessory.
3. Power / NMEA 2000 connection — Connects to 12 V DC power supply / NMEA 2000 or SeaTalkng® backbone.
4. Optional grounding point — Connects to Vessel RF ground, or negative battery terminal. Refer to [p.44 — Grounding — optional dedicated drain wire](#) section for details.
5. Transducer connection — Connects directly to RealVision™ 3D transducers or other transducers via adaptor cables.

Note: Chartplotter only variant Axiom™+ MFDs require a networked sonar module to enable sonar features.

Connecting cables


Follow the steps below to connect the cable(s) to your product.

1. Ensure that the vessel's power supply is switched off.

2. Ensure that the device being connected has been installed in accordance with the installation instructions supplied with that device.
3. Ensuring correct orientation, push cable connectors fully onto the corresponding connectors.
4. Engage any locking mechanism to ensure a secure connection (e.g.: turn locking collars clockwise until tight, or in the locked position).
5. Ensure any bare ended wire connections are suitably insulated to prevent shorting and corrosion due to water ingress.

4.2 Power connection

The power cable must be connected to a 12 V dc power supply, this can be achieved by connecting directly to a battery, or via the distribution panel. For 24 V vessels a suitable voltage converter is required. The product is protected against reverse polarity.



1. Power/NMEA 2000 cable connects to the rear of the display.
2. Ground wire connects to RF ground point, if no ground point is available connect to the battery negative (-) terminal.
3. Positive (Red) wire connects to battery positive (+) terminal.
4. Waterproof fuse holder with 7 A fuse must be fitted (not supplied)
5. Negative wire connects to battery negative (-) terminal.

In-line fuse and thermal breaker ratings

The following in-line fuse and thermal breaker ratings apply to your product:

In-line fuse rating	Thermal breaker rating
7 A	7 A

Note:

- The suitable fuse rating for the thermal breaker is dependent on the number of devices you are connecting. If in doubt consult an authorized Raymarine dealer.
- Your product's power cable may have an in-line fuse fitted, if not then you must add an in-line fuse / breaker to the positive wire of your product's power connection.

Caution: Power supply protection

When installing this product ensure the power source is adequately protected by means of a suitably-rated fuse or thermal circuit breaker.

Power distribution


Recommendations and best practice.

- The product is supplied with a power cable, either as a separate item or a captive cable permanently attached to the product. Only use the power cable supplied with the product. Do NOT use a power cable designed for, or supplied with, a different product.
- Refer to the *Power connection* section for more information on how to identify the wires in your product's power cable, and where to connect them.
- See below for more information on implementation for some common power distribution scenarios:

Important:


- When planning and wiring, take into consideration other products in your system, some of which (e.g. sonar modules) may place large power demand peaks on the vessel's electrical system, which may impact the voltage available to other products during the peaks.
- The information provided below is for guidance only, to help protect your product. It covers common vessel power arrangements, but does NOT cover every scenario. If you are unsure how to provide the correct level of protection, please consult an authorized dealer or a suitably qualified professional marine electrician.

Implementation — connection to distribution panel (Recommended)



1	Waterproof fuse holder containing a suitably-rated inline fuse must be fitted. For suitable fuse rating, refer to: <i>In-line fuse and thermal breaker ratings</i> .
2	Product power cable.
3	Drain wire connection point.

- It is recommended that the supplied power cable is connected to a suitable breaker or switch on the vessel's distribution panel or factory-fitted power distribution point.
- The distribution point should be fed from the vessel's primary power source by 8 AWG (8.36 mm²) cable.
- Ideally, all equipment should be wired to individual suitably-rated thermal breakers or fuses, with appropriate circuit protection. Where this is not possible and more than 1 item of equipment shares a breaker, use individual in-line fuses for each power circuit to provide the necessary protection.




1	Positive (+) bar
2	Negative (-) bar
3	Circuit breaker
4	Waterproof fuse holder containing a suitably-rated inline fuse must be fitted. For suitable fuse rating, refer to: <i>In-line fuse and thermal breaker ratings</i> .

Important:

Observe the recommended fuse / breaker ratings provided in the product's documentation, however be aware that the suitable fuse / breaker rating is dependent on the number of devices being connected.

Implementation — direct connection to battery

- Where connection to a power distribution panel is not possible, the power cable supplied with your product may be connected directly to the vessel's battery, via a suitably rated fuse or breaker.
- The power cable supplied with your product may NOT include a separate drain wire. If this is the case, only the power cable's red and black wires need to be connected.
- If the power cable is NOT supplied with a fitted inline fuse, you MUST fit a suitably rated fuse or breaker between the red wire and the battery's positive terminal.
- Refer to the inline fuse ratings provided in the product's documentation.
- If you need to extend the length of the power cable supplied with your product, ensure you observe the dedicated *Power cable extensions* advice provided in the product's documentation.



1	Waterproof fuse holder containing a suitably-rated inline fuse must be fitted. For suitable fuse rating, refer to: <i>In-line fuse and thermal breaker ratings</i> .
2	Product power cable.
3	Drain wire connection point.

Battery connection scenario A:

Suitable for a vessel with a common RF ground point. In this scenario, if your product's power cable is supplied with a separate drain wire then it should be connected to the vessel's common ground point.

Battery connection scenario B:

Suitable for a vessel without a common grounding point. In this case, if your product's power cable is supplied with a separate drain wire then it should be connected directly to the battery's negative terminal.

Power cable extension

If you need to extend the length of the power cable supplied with your product, ensure you observe the following advice:

- The power cable for each unit in your system should be run as a separate, single length of 2-wire cable from the unit to the vessel's battery or distribution panel.
- Ensure that the extension cable is of a sufficient gauge for the supply voltage and the total load of the device and the length of the cable run. Refer to the following table for typical **minimum** power cable wire gauges.

Cable length in meters (feet)	Wire gauge in AWG (mm ²) for 12 V supply	Wire gauge in AWG (mm ²) for 24 V supply
<8 (<25)	16 (1.31 mm ²)	18 (0.82 mm ²)
16 (50)	14 (2.08 mm ²)	18 (0.82 mm ²)
24 (75)	12 (3.31 mm ²)	16 (1.31 mm ²)
>32 (>100)	10 (5.26 mm ²)	16 (1.31 mm ²)

Important:

Be aware that some products in your system (such as sonar modules) can create voltage peaks at certain times, which may impact the voltage available to other products during the peaks.

Important: To ensure power cables (including any extension) are of a sufficient gauge, ensure that there is a continuous **minimum** voltage of **10.8 V dc** at the end of the cable where it enters the product's power connector, even with a fully flat battery at 11 V dc. (Do not assume that a flat battery is at 0 V dc. Due to the discharge profile and internal chemistry of batteries, the current drops much faster than the voltage. A "fully flat" battery still shows a positive voltage, even if it doesn't have enough current to power your device.)

Grounding

Ensure that you observe any additional grounding advice provided in the product's documentation.

More information

It is recommended that best practice is observed in all vessel electrical installations, as detailed in the following standards:

- BMEA Code of Practice for Electrical and Electronic Installations in Boats
- NMEA 0400 Installation Standard
- ABYC E-11 AC & DC Electrical Systems on Boats
- ABYC A-31 Battery chargers and Inverters
- ABYC TE-4 Lightning Protection



Warning: Product grounding

Before applying power to this product, ensure it has been correctly grounded, in accordance with the instructions provided.



Warning: Positive ground systems


Do not connect this unit to a system which has positive grounding.

Grounding — optional dedicated drain wire

Frequencies emitted from equipment such as switch mode power supplies or MF/HF transmitters etc. can cause interference with your MFD's touchscreen. If you experience issues with touchscreen performance, fitting an additional dedicated drain wire can resolve the issue.

Note:

The additional wire supplements the drain wire (shield) that is part of the product's power cable and should **ONLY** be used when touchscreen interference is observed.



Connect one end of the additional drain wire (not supplied) to your product.

Connect the other end of the additional drain wire to the same point as the power cable drain wire (shield). This will be either the vessel's RF ground point, or on vessels without an RF ground system, the negative battery terminal.

The dc power system should be either:

- Negative grounded, with the negative battery terminal connected to the vessel's ground; or
- Floating, with neither battery terminal connected to the vessel's ground.

If several items require grounding, they may first be connected to a single local point (e.g. within a switch panel), with this point connected via a single, appropriately-rated conductor, to the vessel's common RF ground point.

Implementation

The preferred minimum requirement for the path to ground is via a flat tinned copper braid, with a 30 A rating (1/4 inch) or greater. If this is not possible, an equivalent stranded wire conductor may be used, rated as follows:

- for runs of <1 m (3 ft), use 6 mm² (#10 AWG) or greater.
- for runs of >1 m (3 ft), use 8 mm² (#8 AWG) or greater.


In any grounding system, always keep the length of connecting braid or wires as short as possible.

References

- ISO10133/13297
- BMEA code of practice
- NMEA 0400

4.3 NMEA 2000 (SeaTalkng®) connection

The MFD can transmit and receive data from devices connected on a compliant CAN bus network that the MFD is also connected to. The MFD is connected to the backbone using the DeviceNet connector on the Power/NMEA 2000 cable.



1. Power/NMEA 2000 cable connects to the rear of the MFD.
2. DeviceNet (Micro-C 5 pin male) connector connects to NMEA 2000 network or SeaTalkng® via adaptor cable.
3. DeviceNet (5 pin female) connector.
4. Adaptor cable connects to SeaTalkng® backbone or DeviceNet spur cable connects to NMEA 2000 network. Available cables
 - A06045 — Female DeviceNet to SeaTalkng® cable, shown.
 - E05026 — Female DeviceNet to bare end wires.

Note:


1. SeaTalkng® and NMEA 2000 devices must be connected to a correctly terminated backbone that the MFD is also connected to. Devices cannot be connected directly to the MFD.
2. Refer to the instructions supplied with your SeaTalkng® / NMEA 2000 device for details on creating a backbone.

4.4 Transducer connection

If your MFD includes a built-in sonar module then you can connect a transducer to your MFD.

Note:

RealVision™ transducers connect directly, all other transducer type require an adaptor cable.



Note:

1. Refer to [2.3 Compatible transducers for Axiom™+ RV Multifunction displays](#) for more information on compatible transducers for your MFD variant.
2. Transducer extension cables are available.
3. MFDs that do not have a built-in sonar module can be connected to a transducer via an networked sonar module.

RealVision™ 3D transducer extension cable

For best performance, cable runs should be kept to a minimum. However, for some installations it may be necessary to extend the transducer cable.

- 3 m (9.8 ft), 5 m (16.4 ft), and 8 m (26.2 ft) transducer extension cables are available (part numbers: 3 m - A80475, 5 m - A80476, 8 m - A80477).
- It is recommended that a maximum of two cable extensions are used, with the total cable length not exceeding 18 m (59 ft).

DownVision™ transducer extension cable

For best performance, cable runs should be kept to a minimum. However, for some installations it may be necessary to extend the transducer cable.

- A 4 m (13.1 ft.) Transducer extension cable (A80273) is available.
- It is recommended that only one cable extension is used.

Axiom transducer adaptor cables

The following adaptor cables are available to enable connection of a wider selection of transducers.

A80488	Axiom RV to 7-pin Embedded Transducer Adapter
A80489	Axiom RV to 7-pin CP370 Transducer Adapter
A80490	Axiom RV to 9-pin DV Transducer Adapter
A80491	Axiom RV to 25-pin RV & 7-pin Embedded Transducers Y-Cable
A80492	Axiom RV to 25-pin RV & 7-pin CP370 Transducers Y-Cable
A80493	Axiom RV to 7-pin Embedded & 9-pin DV Transducers Y-Cable
A80494	Axiom RV to 7-pin CP370 & 9-pin DV Transducers Y-Cable


Caution: Transducer cable

- Do NOT use the transducer cable to lift or suspend the transducer; always support the transducer body directly during installation.
- Do NOT cut, shorten, or splice the transducer cable.
- Do NOT remove the connector.

If the cable is cut, it cannot be repaired. Cutting the cable will also void the warranty.

4.5 Network connection

Your MFD can be directly connected to compatible products using the RayNet connections. Your MFD can also be connected to a SeaTalkhs[®] network when using a suitable network switch.



1. RayNet to RayNet cable — Connect one end of the RayNet cable to your MFD and the opposite end to a RayNet device or RayNet network switch.
2. RayNet to RJ45 cable — Connect the RayNet end of the cable to your MFD and the opposite end to an RJ45 device or RJ45 network switch or coupler.
3. Compatible network devices, such as a Network switch, Radar scanner, Sonar module, Thermal camera etc.

Note:

- Refer to the instructions supplied with your network product for specific connection information.
- Refer to [Chapter 9 Spares and accessories](#) for a list of available network cables.

4.6 Accessory connection

The RCR-SDUSB or RCR-2 (available separately) can be connected to your MFD using the Accessory connection.

RCR connection


The following functions require a card reader attached to the MFD:

- use of electronic cartography — alternatively cartography can be shared from a networked MFD that does have a card reader attached.
- updating product software — alternatively if your MFD has a connection to the internet you can check online for software updates.
- import and export user data (waypoints, routes and tracks) — alternatively user data can be imported and exported from a networked MFD that does have a card reader attached.
- backup and restore settings — alternatively settings can be backed up and restored from a networked MFD that does have a card reader attached.
- viewing pdf files
- ⁽¹⁾ capturing and viewing screenshots or images (.png, .jpg files)
- ⁽²⁾ recording and viewing video files (.mov files)
- installation of third-party LightHouse app (.apk files) (for installation only; apps cannot be run directly from storage device).

Important:

1. To store, **External SD** or **External USB** must be selected as the **Screenshot File** location on the **This display** tab in the main MFD settings menu (accessible from Homescreen).
2. To store, **External SD** or **External USB** must be selected as the **Save Files** location on the **Photo & Video recording** tab in the Video app settings menu.

In addition to the storage uses listed above, the USB slot on the RCR-SDUSB can also supply 0.5A of current to charge mobile devices.



Device	Supported media
RCR-SDUSB (A80440))	1x SD card (or MicroSD card when using an SD card adaptor) 1x USB (Type A connector) (e.g. for connection of an external USB hard drive or pen / flash drive)
RCR-2 (A80218))	2x MicroSD card

For installation details for these devices, please refer to the instructions provided with your accessory.



Warning: USB device power

Do NOT connect any device to the product's USB connection that requires an external power source.

Chapter 5: Maintaining your display

Chapter contents

- [5.1 Service and maintenance on page 50](#)
- [5.2 Product cleaning on page 50](#)

5.1 Service and maintenance

This product contains no user serviceable components. Please refer all maintenance and repair to authorized Raymarine dealers. Unauthorized repair may affect your warranty.



Warning: High voltage

This product contains high voltage. Adjustments require specialized service procedures and tools only available to qualified service technicians. There are no user serviceable parts or adjustments. The operator should never remove the cover or attempt to service the product.



Warning: FCC Warning (Part 15.21)

Changes or modifications to this equipment not expressly approved in writing by Raymarine Incorporated could violate compliance with FCC rules and void the user's authority to operate the equipment.

Caution: Sun covers

- If your product is supplied with a sun cover, to protect against the damaging effects of ultraviolet (UV) light, always fit the sun cover when the product is not in use.
- To avoid potential loss, sun covers must be removed when travelling at high speed, whether in water or when the vessel is being towed.

Routine equipment checks

It is recommended that you perform the following routine checks, on a regular basis, to ensure the correct and reliable operation of your equipment:

- Examine all cables for signs of damage or wear and tear.
- Check that all cables are securely connected.

5.2 Product cleaning

Best cleaning practices.

When cleaning products:

- Lightly rinse or flush with clean, cool fresh water.
- Do NOT use: abrasive, acidic, ammonia, solvent or other chemical based cleaning products.
- Do NOT use a jet wash.

Cleaning the display screen

The touchscreen has an oleophobic protective coating. The oleophobic coating is a fingerprint resistant, oil repelling coating used to protect your display screen. To remove fingerprints simply wipe the screen gently with a clean, lint-free cloth, such as a microfibre cloth. For more stubborn smears follow the steps below:

Important:

Do NOT use abrasive cloth or abrasive cleaning fluid to clean the screen as this will degrade the protective coating and could scratch the screen.

1. Switch off the power to the display.
2. Clean the screen using a mild detergent solution and a clean, lint free cloth to remove all dirt particles and salt deposits.
3. Rinse the screen with fresh, clean water to remove any remaining detergent.

Important:

Leaving detergent on the glass may deteriorate the protective coating.

4. Allow the screen to dry naturally.
5. If any smears remain, very gently wipe the screen with a fresh, clean, lint-free cloth.

Cleaning the display case

The display is a sealed unit and does not require regular cleaning. If it is necessary to clean the display, follow this basic procedure:

1. Switch off the power to the display.
2. Wipe the case with a clean, lint-free cloth.
3. If necessary, use a mild detergent to remove grease marks.

Disinfecting the display

In installations where MFDs have multiple users (e.g.: on charter boats), the touchscreen and control buttons should be disinfected. You should use a 70% isopropyl alcohol wipe.

Important:

- If wipes are unavailable then you can also spray 70% isopropyl alcohol onto a lint free cloth (such as a microfibre cloth), and wipe the display. Do NOT spray directly onto the touchscreen.
- Do NOT use a stronger concentration of alcohol, as this could strip the protective coating on your screen.
- Do NOT use abrasive cloth or abrasive cleaning fluid to clean the screen, as this will degrade the protective coating and could scratch the screen.

1. Switch off the power to the display.
2. Follow the instructions for cleaning your display screen.
3. Using a 70% isopropyl alcohol wipe, gently wipe all surfaces and control buttons.
4. Using a second 70% isopropyl alcohol, wipe very gently the surface of the touchscreen.
5. Rinse the screen with fresh, clean water to remove all traces of the chemicals used in the wipe.
6. Allow the screen to dry naturally.
7. If any smears remain, very gently wipe the screen with a clean, microfibre cloth.

Cleaning the sun cover

The supplied sun cover features an adhesive surface. In certain conditions unwanted contaminants may stick to this surface. To avoid damaging the monitor display, clean the sun cover regularly following this procedure:

1. Carefully remove the sun cover from the display.
2. Rinse the sun cover with fresh water to remove all dirt particles and salt deposits.
3. Allow the sun cover to dry naturally.

Chapter 6: Troubleshooting

Chapter contents

- [6.1 Troubleshooting on page 54](#)
- [6.2 LED Diagnostics on page 54](#)
- [6.3 Power up troubleshooting on page 55](#)
- [6.4 GNSS \(GPS\) troubleshooting on page 56](#)
- [6.5 Sonar troubleshooting on page 57](#)
- [6.6 Wi-Fi troubleshooting on page 60](#)
- [6.7 Touchscreen troubleshooting on page 63](#)
- [6.8 Miscellaneous troubleshooting on page 64](#)

6.1 Troubleshooting

The troubleshooting information provides possible causes and corrective action required for common problems associated with installation and operation of your product.

Before packing and shipping, all Raymarine products are subjected to comprehensive testing and quality assurance programs. If you do experience problems with your product this section will help you to diagnose and correct problems in order to restore normal operation.

If after referring to this section you are still having problems with your product, please refer to the Technical support section of this manual for useful links and Raymarine Product Support contact details.

6.2 LED Diagnostics

The Power swipe area is illuminated using LEDs. The LEDs color and flash sequence will identify the status of the MFD along with any error codes.

Normal states

MFD status	LED color	LED state
On	White	On (Brightness increases with display brightness)
Off	Red	On
Recovery	Blue	On

Error states

Fault	LED color	LED state
Low voltage	Red	Slow flash — one flash per second
High voltage	Red	Fast flash — two flashes per second
High temperature	Red and Blue	Alternating

6.3 Power up troubleshooting

Product does not turn on or keeps turning off

Possible causes	Possible solutions
Blown fuse / tripped breaker.	1. Check condition of relevant fuses and breakers and connections, replace if necessary. (Refer to the <i>Technical Specification</i> section of your product's installation instructions for fuse ratings.) 2. If fuse keeps blowing check for cable damage, broken connector pins or incorrect wiring.
Poor / damaged / insecure power supply cable / connections	1. Check that the power cable connector is correctly orientated and fully inserted into the display connector and locked in position. 2. Check the power supply cable and connectors for signs of damage or corrosion, and replace if necessary. 3. With the display turned on, try flexing the power cable near to the display connector to see if this causes the unit to restart or lose power. Replace if necessary. 4. Check the vessel's battery voltage and the condition of the battery terminals and power supply cables, ensuring connections are secure, clean and free from corrosion. Replace if necessary. 5. With the product under load, using a multi-meter, check for high voltage drop across all connectors / fuses etc, and replace if necessary.
Incorrect power connection	The power supply may be wired incorrectly, ensure the installation instructions have been followed.

Product will not start up (restart loop)

Possible causes	Possible solutions
Power supply and connection	See possible solutions from the table above, entitled 'Product does not turn on or keeps turning off'.
Software corruption	1. In the unlikely event that the product's software has become corrupted, try downloading and installing the latest software from the Raymarine website. 2. On display products, as a last resort, attempt to perform a 'Power on Reset'. Be aware that this will delete all settings / presets and user data (such as waypoints and tracks), and revert the unit back to factory defaults.

Performing a power on reset — Axiom™

Important: • Before performing a power on reset ensure you have backed up your settings and user data (waypoints, routes and tracks) to a memory card. • You may also want to save any crash logs that are stored on your MFD to memory card for future reference..
--

1. Switch off power at the breaker to ensure that the MFD is completely powered off, and not in Standby mode. Alternatively, remove the power cable from the display.
2. Power on your MFD, and within approximately 10 seconds, swipe your finger from right to left (opposite direction to powering on) across the **Power** button swipe area 5 times.
Recovery options are displayed.
3. Swipe your finger from right to left twice to highlight **Wipe data/factory reset**.
4. Swipe your finger from left to right once to accept.
5. Swipe your finger from right to left once to highlight **Yes**.
6. Swipe your finger from left to right once to restore your MFD to factory default settings.
7. When **Data wipe complete** is displayed, swipe your finger from left to right to restart your MFD.

6.4 GNSS (GPS) troubleshooting

Potential problems with the GNSS (GPS) receiver and possible causes and solutions are described here.

Problem	Possible causes	Possible solutions
“No Fix” GNSS status icon is displayed.	Geographic location or prevailing conditions preventing satellite fix.	Check periodically to see if a fix is obtained in better conditions or another geographic location.
	GNSS (GPS) connection fault.	Ensure that external GNSS connections and cabling are correct and fault free.
	External GNSS (GPS) receiver in poor location. For example: • Below decks. • Close proximity to transmitting equipment such as VHF radio.	Ensure GNSS (GPS) receiver has a clear view of the sky.
	GNSS (GPS) installation problem.	Refer to the installation instructions.
Note: A GNSS Status screen is accessible from the display. This provides satellite signal strength and other relevant information.		

6.5 Sonar troubleshooting

Problems with the sonar and their possible causes and solutions are described here.

Scrolling image is not being displayed

Possible causes	Possible solutions
Sonar disabled	Select Ping Enable from the Sonar app's Sounder menu.
Incorrect transducer selected	Check that the correct transducer is selected in the Sonar app's Transducer menu.
Damaged cables	1. Check that the transducer cable connector is fully inserted and locked in position. 2. Check the power supply cable and connectors for signs of damage or corrosion, replace if necessary. 3. With the unit turned on, try flexing the cable near to the display connector to see if this causes the unit to re-boot/lose power, replace if necessary. 4. Check the vessel's battery voltage, the condition of the battery terminals and power supply cables, ensuring connections are secure, clean and free from corrosion, replace if necessary. 5. With the product under load, using a multi-meter, check for high voltage drop across all connectors/fuses etc (this can cause the Sonar applications to stop scrolling or the unit to reset/turn off), replace if necessary.
Damaged or fouled transducer	Check the condition of the transducer ensuring it is not damaged and is free from debris/fouling, clean or replace as necessary.
Wrong transducer fitted	Ensure the transducer is compatible with your system.
External sonar module: SeaTalkhs™ / RayNet network problem.	• Check that the unit is correctly connected to the multifunction display or Raymarine network switch. If a crossover coupler or other coupler cable / adapter is used, check all connections ensuring connections are secure, clean and free from corrosion, replace if necessary.
External sonar module: Software mismatch between equipment may prevent communication.	Ensure all Raymarine products contain the latest available software, check the Raymarine website: www.raymarine.com/software for software compatibility.

No depth reading / lost bottom lock

Possible causes	Possible solutions
Transducer location	Check that the transducer has been installed in accordance with the instructions provided with the transducer.
Transducer angle	If the transducer angle is too great the beam can miss the bottom, adjust transducer angle and recheck.
Transducer kicked-up	If the transducer has a kick-up mechanism, check that it has not kicked up due to hitting an object.
Power source insufficient	With the product under load, using a multi-meter, check the power supply voltage as close to the unit as possible to establish actual voltage when the current is flowing. (Check your product's Technical specification for power supply requirements.)
Damaged or fouled transducer	Check the condition of the transducer ensuring it is not damaged and is free from debris / fouling.

Possible causes	Possible solutions
Damaged cables	1. Check the unit's connector for broken or bent pins. 2. Check that the cable connector is fully inserted into the unit and that the locking collar is in the locked position. 3. Check the cable and connectors for signs of damage or corrosion, replace if necessary. 4. With the unit turned on, try flexing the power cable near to the display connector to see if this causes the unit to re-boot/loose power, replace if necessary. 5. Check the vessel's battery voltage, the condition of the battery terminals and power supply cables, ensuring connections are secure, clean and free from corrosion, replace if necessary. 6. With the product under load, using a multi-meter, check for high voltage drop across all connectors/fuses etc (this can cause the Sonar applications to stop scrolling or the unit to reset/turn off), replace if necessary.
Vessel speed too high	Slow vessel speed and recheck.
Bottom too shallow or too deep	The bottom depth may be outside of the transducers depth range, move vessel to shallower or deeper waters as relevant and recheck.

Poor / problematic image

Possible causes	Possible solutions
Vessel stationary	Fish arches are not displayed if the vessel is stationary; fish will appear on the display as straight lines.
Scrolling paused or speed set too low	Unpause or increase sonar scrolling speed.
Sensitivity settings may be inappropriate for present conditions.	Check and adjust sensitivity settings or perform a Sonar reset.
Damaged cables	1. Check the unit's connector for broken or bent pins. 2. Check that the cable connector is fully inserted into the unit and that the locking collar is in the locked position. 3. Check the cable and connectors for signs of damage or corrosion, replace if necessary. 4. With the unit turned on, try flexing the power cable near to the display connector to see if this causes the unit to re-boot/loose power, replace if necessary. 5. Check the vessel's battery voltage, the condition of the battery terminals and power supply cables, ensuring connections are secure, clean and free from corrosion, replace if necessary. 6. With the product under load, using a multi-meter, check for high voltage drop across all connectors/fuses etc (this can cause the Sonar applications to stop scrolling or the unit to reset/turn off), replace if necessary.

Possible causes	Possible solutions
Transducer location	• Check that the transducer has been installed in accordance with the instructions provided with the transducer. • If a transom mount transducer is mounted too high on the transom it may be lifting out of the water, check that the transducer face is fully submerged when planing and turning.
Transducer kicked-up	If the transducer has a kick-up mechanism, check that it has not kicked up due to hitting an object.
Damaged or fouled transducer	Check the condition of the transducer ensuring it is not damaged and is free from debris / fouling.
Damaged transducer cable	Check that the transducer cable and connection is free from damage and that the connections are secure and free from corrosion.
Turbulence around the transducer at higher speeds may affect transducer performance	Slow vessel speed and recheck.
Interference from another transducer	1. Turn off the transducer causing the interference. 2. Reposition the transducers so they are further apart.
Unit power supply fault	Check the voltage from the power supply, if this is too low it can affect the transmitting power of the unit.

6.6 Wi-Fi troubleshooting

Before troubleshooting problems with your Wi-Fi connection, ensure that you have followed the Wi-Fi location requirements guidance provided in the relevant installation instructions and performed a power cycle/reboot of the devices you are experiencing problems with.

Cannot find network

Possible cause	Possible solutions
Wi-Fi not currently enabled on devices.	Ensure Wi-Fi is enabled on both Wi-Fi devices and rescan available networks.
Some devices may automatically turn off Wi-Fi when not in use to save power.	Power cycle / reboot devices and rescan available networks.
Device not broadcasting.	1. Try to enable broadcasting of the device's network using the Wi-Fi settings on the device you are trying to connect to. 2. You may still be able to connect to the device, when it is not broadcasting, by manually entering the device's Wi-Fi Name / SSID and passphrase in the connection settings of the device you are trying to connect.
Devices out of range or signal being blocked.	Move devices closer together or, if possible remove the obstructions and then rescan available network.

Cannot connect to network

Possible cause	Possible solutions
Some devices may automatically turn off Wi-Fi when not in use to save power.	Power cycle/reboot devices and retry the connection.
Trying to connect to the wrong Wi-Fi network	Ensure you are trying to connect to the correct Wi-Fi network, the Wi-Fi network's name can be found in the Wi-Fi settings on the broadcasting device (the device that you are trying to connect to).
Incorrect network credentials	Ensure you are using the correct passphrase, the Wi-Fi network's passphrase can be found in the Wi-Fi settings on the broadcasting device (the device that you are trying to connect to).
Bulkheads, decks and other heavy structure can degrade and even block the Wi-Fi signal. Depending on the thickness and material used it may not always be possible to pass a Wi-Fi signal through certain structures	1. Try repositioning the devices so the structure is removed from the direct line of sight between the devices, or 2. If possible use a wired connection instead.
Interference being caused by other Wi-Fi enabled or older Bluetooth enabled devices (Bluetooth and Wi-Fi both operate in the 2.4 GHz frequency range, some older bluetooth devices may interfere with Wi-Fi signals.)	1. Change the Wi-Fi Channel of the device you are trying to connect to and retry the connection. You can use free Wi-Fi analyzer apps on your smart device to help you choose a better channel (channel with least traffic). 2. Temporarily disable each wireless device in turn until you have identified the device causing the interference.

Possible cause	Possible solutions
Interference caused by other devices that use the 2.4GHz frequency See list below of some common devices that use the 2.4GHz frequency: • Microwave ovens • Fluorescent lighting • Cordless phones / baby monitors • Motion sensors	Temporarily switch off each device in turn until you have identified the device causing the interference, then remove or reposition the offending device(s).
Interference caused by electrical and electronic devices and associated cabling could generate an electromagnetic field which may interfere with the Wi-Fi signal.	Temporarily switch off each item in turn until you have identified the device causing the interference, then remove or reposition the offending device(s).

Connection extremely slow and or keeps dropping out

Possible cause	Possible solutions
Wi-Fi performance degrades over distance so products farther away will receive less network bandwidth. Products installed close to their maximum Wi-Fi range will experience slow connection speeds, signal drop outs or not being able to connect at all.	• Move devices closer together. • For fixed installations such as a Quantum Radar, enable the Wi-Fi connection on an MFD installed closer to the device.
Interference being caused by other Wi-Fi enabled or older Bluetooth enabled devices (Bluetooth and Wi-Fi both operate in the 2.4 GHz frequency range, some older bluetooth devices may interfere with Wi-Fi signals.)	1. Change the Wi-Fi Channel of the device you are trying to connect to and retry the connection. You can use free Wi-Fi analyzer apps on your smart device to help you choose a better channel (channel with least traffic). 2. Temporarily switch off each device in turn until you have identified the device causing the interference, then remove or reposition the offending device(s).
Interference from devices on other vessels. When in close proximity to other vessels, for example, when moored up in a marina, many other Wi-Fi signals may be present.	1. Change the Wi-Fi Channel of the device you are trying to connect to and retry the connection. You can use free Wi-Fi analyzer apps on your smart device to help you choose a better channel (channel with least traffic). 2. If possible, move your vessel to a location with less Wi-Fi traffic.

Network connection established but no data

Possible cause	Possible solutions
Connected to the wrong network.	Ensure that your devices is connected to the correct network.
Device software incompatibility	Ensure both devices are running the latest available software.
It may be possible that the device has become defective	1. Try updating software to a later version, or 2. try reinstalling the software. 3. Obtain new replacement device.

Mobile application running slowly or not at all

Possible cause	Possible solutions
Raymarine app not installed	Install mobile app from relevant app store.
Raymarine app version not compatible with MFD software	Ensure mobile app and MFD software are latest available versions.
Mobile apps not enabled on MFD	Enable “Viewing only” or “Remote Control” as required in the Mobile Apps setting on your MFD.

6.7 Touchscreen troubleshooting

Problems with the touchscreen and their possible causes and solutions are described here.

Problem	Possible causes	Possible solutions
Touchscreen does not operate as expected.	TouchLock is enabled.	Swipe your finger from left to right across the Power button swipe area to de-activate the TouchLock.
	Screen is not being operated with bare fingers, for example gloves are being worn.	Bare fingers must make contact with the screen for correct operation. Alternatively you may use conductive gloves.
	Water deposits on the screen.	Carefully clean and dry the screen in accordance with the instructions provided.

6.8 Miscellaneous troubleshooting

Miscellaneous problems and their possible causes and solutions are described here.

Problem	Possible causes	Possible solutions
Display behaves erratically: • Frequent unexpected resets. • System crashes or other erratic behavior.	Intermittent problem with power to the display.	Check relevant fuses and breakers.
		Check that the power supply cable is sound and that all connections are tight and free from corrosion.
		Check that the power source is of the correct voltage and sufficient current.
	Software mismatch on system (upgrade required).	Go to www.raymarine.com and click on support for the latest software downloads.
	Corrupt data / other unknown issue.	Perform a factory reset. Important: This will result in the loss of any settings and data (such as waypoints) stored on the product. Save any important data to a memory card before resetting.

Chapter 7: Technical support

Chapter contents

- 7.1 Raymarine product support and servicing on page 66
- 7.2 Learning resources on page 68

7.1 Raymarine product support and servicing

Raymarine provides a comprehensive product support service, as well as warranty, service, and repairs. You can access these services through the Raymarine website, telephone, and e-mail.

Product information

If you need to request service or support, please have the following information to hand:

- Product name.
- Product identity.
- Serial number.
- Software application version.
- System diagrams.

You can obtain this product information using diagnostic pages of the connected MFD.

Servicing and warranty

Raymarine offers dedicated service departments for warranty, service, and repairs.

Don't forget to visit the Raymarine website to register your product for extended warranty benefits: <http://www.raymarine.co.uk/display/?id=788>.

Region	Contact
United Kingdom (UK), EMEA, and Asia Pacific	• E-Mail: emea.service@raymarine.com • Tel: +44 (0)1329 246 932
United States (US)	• E-Mail: rm-usrepair@flir.com • Tel: +1 (603) 324 7900

Web support

Please visit the “Support” area of the Raymarine website for:

- **Manuals and Documents** — <http://www.raymarine.com/manuals>
- **Technical support forum** — <http://forum.raymarine.com>
- **Software updates** — <http://www.raymarine.com/software>


Worldwide support

Region	Contact
United Kingdom (UK), EMEA, and Asia Pacific	• E-Mail: support.uk@raymarine.com • Tel: +44 (0)1329 246 777
United States (US)	• E-Mail: support@raymarine.com • Tel: +1 (603) 324 7900 (Toll-free: +800 539 5539)
Australia and New Zealand (Raymarine subsidiary)	• E-Mail: aus.support@raymarine.com • Tel: +61 2 8977 0300
France (Raymarine subsidiary)	• E-Mail: support.fr@raymarine.com • Tel: +33 (0)1 46 49 72 30
Germany (Raymarine subsidiary)	• E-Mail: support.de@raymarine.com • Tel: +49 (0)40 237 808 0
Italy (Raymarine subsidiary)	• E-Mail: support.it@raymarine.com • Tel: +39 02 9945 1001
Spain (Authorized Raymarine distributor)	• E-Mail: sat@azimut.es • Tel: +34 96 2965 102
Netherlands (Raymarine subsidiary)	• E-Mail: support.nl@raymarine.com • Tel: +31 (0)26 3614 905

Region	Contact
Sweden (Raymarine subsidiary)	- E-Mail: support.se@raymarine.com - Tel: +46 (0)317 633 670
Finland (Raymarine subsidiary)	- E-Mail: support.fi@raymarine.com - Tel: +358 (0)207 619 937
Norway (Raymarine subsidiary)	- E-Mail: support.no@raymarine.com - Tel: +47 692 64 600
Denmark (Raymarine subsidiary)	- E-Mail: support.dk@raymarine.com - Tel: +45 437 164 64
Russia (Authorized Raymarine distributor)	- E-Mail: info@mikstmarine.ru - Tel: +7 495 788 0508

Viewing product information (LightHouse™ 3)

Use the **Settings** menu to view hardware and software information about your MFD, and connected products.




1. Select **Settings**, from the Homescreen.
The **Getting started** menu contains hardware and software information for your MFD.
2. You can view further information about your MFD, or view information about products networked using SeaTalkhs® and SeaTalkng® / NMEA 2000, by selecting the **Network** tab, then:
 - i. to display detailed software information and your MFD's network IP address, select your MFD from the list.
 - ii. to display detailed diagnostics information for all products, select **Product info** from the **Diagnostics** pop over menu.

7.2 Learning resources

Raymarine has produced a range of learning resources to help you get the most out of your products.

Video tutorials

	Raymarine official channel on YouTube: • YouTube LightHouse™ 3 tips and tricks: • Raymarine website
	Video Gallery: • Raymarine website

Note:

- Viewing the videos requires a device with an Internet connection.
- Some videos are only available in English.

Training courses

Raymarine regularly runs a range of in-depth training courses to help you make the most of your products. Visit the Training section of the Raymarine website for more information:

- <http://www.raymarine.co.uk/view/?id=2372>

Technical support forum

You can use the Technical support forum to ask a technical question about a Raymarine product or to find out how other customers are using their Raymarine equipment. The resource is regularly updated with contributions from Raymarine customers and staff:

- <http://forum.raymarine.com>

Chapter 8: Technical specification

Chapter contents

- [8.1 Axiom+ technical specification on page 70](#)
- [8.2 RealVision™ 3D sonar specification on page 71](#)
- [8.3 Internal GNSS \(GPS / GLONASS\) receiver specification on page 71](#)

8.1 Axiom+ technical specification

Power

	Axiom™ 7+	Axiom™ 9+	Axiom™ 12+
Nominal supply voltage:	12 V dc		
Operating voltage range:	8 V dc to 16 V dc		
Fuse requirements:	• Inline fuse = 7 Amp, or • Thermal breaker = 7 Amp		
Power consumption: (Maximum @ 12 V dc)	• Chartplotter — 7.34 Watts • RV — 9.84 Watts	• Chartplotter — 8.95 Watts • RV — 11.98 Watts	• Chartplotter — 15.48 Watts • RV — 18.96 Watts

Note:

Power consumption figures for RV variant displays were taken with an RV-100 transducer connected.

Environmental

	Axiom™ 7	Axiom™ 9	Axiom™ 12
Operating temperature range:	-25°C to + 55°C		
Storage temperature range:	-30°C to + 70°C		
Humidity:	up to 93% @ 40°C		
Water ingress protection:	IPx6 and IPx7		

LCD specification

	Axiom™ 7+	Axiom™ 9+	Axiom™ 12+
Size (diagonal):	7.0"	9.0"	12.1"
Type:	IPS (In-Plane Switching)		
Color depth:	24 bit		
Resolution:	WSVGA 1024 x 600	Widescreen HD 1080 x 720	WXGA 1280 x 800
Ratio:	15.4:9	16:9	16:10
Illumination:	1500 nits / 1500 cd/m ²		1800 nits / 1800 cd/m ²
Protective coating	Oleophobic		
Viewing angle:	Top 85/ Bottom 85 / Left 85 / Right 85		Top 88 / Bottom 88 / Left 88 / Right 88
Number of simultaneous touches:	2		1 to 16

Data connections

	Axiom™ 7+	Axiom™ 9+	Axiom™ 12+
Transducer:	25 pin RealVision™ type connector		
NMEA 2000:	1 x DeviceNet (male connector built into power cable.)		
Accessory connection:	1 x USB Micro B		
Network:	1 x RayNet type SeaTalkhs™ connector (10/100 Mbits/s)		
Wi-Fi:	1 x 802.11/b/g/n		

	Axiom™ 7+	Axiom™ 9+	Axiom™ 12+
Bluetooth:	1 x Bluetooth V4.0		
LEN (Load Equivalency Number):	1		

Storage

	Axiom™ 7	Axiom™ 9	Axiom™ 12
Internal:	16 GB Solid State		
External microSD card:	1 x MicroSDXC card slot		
External (via RCR-SDUSB accessory):	• 1 x SD card slot • 1 x USB A		
External (via RCR-2 accessory)	2 x MicroSDHC card slots		

8.2 RealVision™ 3D sonar specification

The following specification only applies to RealVision™ 3D products.

Channels:	• 1 x CHIRP sonar • 1 x DownVision™ • 1 x SideVision™ • 1 x RealVision™ 3D
Range:	• CHIRP sonar = 0.6 M (2 ft) to 274 m (900 ft) • DownVision™ = 0.6 M (2 ft) to 183 m (600 ft) • SideVision™ = 0.6 M (2 ft) to 91 m (300 ft) • RealVision™ 3D = 0.6 M (2 ft) to 91 m (300 ft)

8.3 Internal GNSS (GPS / GLONASS) receiver specification

Channels:	Multiple — ability to simultaneously track up to 28 satellites
Cold start:	<2 minutes
Receiver IC Sensitivity:	• 165 dBm (Tracking) • 160 dBm (Acquisition) • 148 dBm (Cold start)
GNSS compatibility:	• GPS • GLONASS • Beidou* • Galileo*
SBAS compatibility:	• EGNOS • GAGAN • MSAS • QZSS • WAAS

Operating frequency:	1574 MHz to 1605 MHz
Signal Acquisition:	Automatic
Almanac Update:	Automatic
Geodetic Datum:	WGS-84 (alternatives can be selected on the MFD)
Refresh Rate:	10 Hz (10 times per second)
Antenna:	• Internal — Ceramic chip mounted near top of unit
Position Accuracy:	• Without SBAS: ≤ 15 metres 95% of the time • With SBAS: ≤ 5 metres 95% of the time

Note:

* Supported in future software update.

Chapter 9: Spares and accessories

Chapter contents

- [9.1 AXIOM accessories on page 74](#)
- [9.2 AXIOM spares on page 75](#)
- [9.3 RayNet to RayNet cables and connectors on page 76](#)
- [9.4 SeaTalkng[®] cables and accessories on page 78](#)

9.1 AXIOM accessories

Part number	Name	Details
A80440	RCR-SDUSB	External MicroSD and USB reader
A80515	Right angled RV transducer adaptor cable	
A80498	7" Front installation kit	Includes : • Front mount adaptor • 2 x bezel pieces • 4 x self-tapping screws • Front mount suncover
A80499	7" Front mount suncover	
A80500	9" Front installation kit	Includes : • Front mount adaptor • 2 x bezel pieces • 4 x self-tapping screws • Front mount suncover
A80501	9" Front mount suncover	
A80502	12" Front installation kit	Includes : • Front mount adaptor • 2 x bezel pieces • 4 x self-tapping screws • Front mount suncover
A80503	12" Front mount suncover	

Axiom transducer adaptor cables

The following adaptor cables are available to enable connection of a wider selection of transducers.

A80488	Axiom RV to 7-pin Embedded Transducer Adapter
A80489	Axiom RV to 7-pin CP370 Transducer Adapter
A80490	Axiom RV to 9-pin DV Transducer Adapter
A80491	Axiom RV to 25-pin RV & 7-pin Embedded Transducers Y-Cable
A80492	Axiom RV to 25-pin RV & 7-pin CP370 Transducers Y-Cable
A80493	Axiom RV to 7-pin Embedded & 9-pin DV Transducers Y-Cable
A80494	Axiom RV to 7-pin CP370 & 9-pin DV Transducers Y-Cable

Legacy MFD adaptor plates

Adaptor plates are available to enable installation of Axiom MFDs in the place of a Legacy MFD.

Existing legacy MFD	Adaptor part number	New MFD	Fixing holes
a9x	A80526	Axiom 9"	Existing
a12x	A80527	Axiom 12"	New
c12x / e12x	A80528	Axiom 12"	Existing
C70 Classic	A80525	Axiom 9"	New

Existing legacy MFD	Adaptor part number	New MFD	Fixing holes
C80 / E80 Classic	A80564	Axiom 9"	Existing
C120 / E120 Classic	A80529	Axiom 12"	Existing
e7 / e7D	A80524	Axiom 7"	Existing


Note:

The adaptor plates have been designed to utilize your legacy MFD's existing cut out and fixing holes. Where it is not possible to reuse existing fixing holes then a mounting template is supplied, which provides the location for the new fixing holes.

9.2 AXIOM spares


Part number	Name	Details
R70523	Power/DeviceNet combined cable 1.5m (4.92 ft)	
R70561	Right angled Power/DeviceNet combined cable 1.5m (4.92 ft)	
R70525	7" Trunnion mount suncover	
R70526	7" Rear cover	For trunnion and rear installation
R70527	7" Surface mount suncover	
R70528	7" Rear mounting kit	Includes 2 x metal brackets, 4 x studs and 4 x thumb nuts
R70524	7" Metal trunnion mounting kit	Includes trunnion and 2 knobs
R70529	9" Metal trunnion mounting kit	Includes trunnion and 2 knobs
R70530	9" Trunnion mount suncover	
R70531	9" Rear mounting kit	Includes 2 x metal brackets, 4 x studs and 4 x thumb nuts
R70532	12" Metal trunnion mounting kit	Includes trunnion and 2 knobs
R70533	12" Trunnion mount suncover	
R70534	12" Rear mounting kit	Includes 2 x metal brackets, 4 x studs and 4 x thumb nuts

9.3 RayNet to RayNet cables and connectors



	Description
1	Standard RayNet connection cable with a RayNet (female) socket on both ends.
2	Right-angle RayNet connection cable with a straight RayNet (female) socket on one end, and a right-angle RayNet (female) socket on the other end. Suitable for connecting at 90° (right angle) to a device, for installations where space is limited.
3	RayNet cable puller (5 pack).
4	RayNet to RayNet right-angle coupler / adapter. Suitable for connecting RayNet cables at 90° (right angle) to devices, for installations where space is limited.
5	Adapter cable with a RayNet (male) plug on both ends. Suitable for joining (female) RayNet cables together for longer cable runs.

RayNet to RJ45 adapter cables



	Description
1	Adapter cable with a RayNet (female) socket on one end, and a waterproof (female) socket on the other end accepting the following cables with an RJ45 SeaTalkhs[®] waterproof locking (male) plug: • A62245 (1.5 m). • A62246 (15 m).
2	Adapter cable with a RayNet (female) socket on one end, and a waterproof (female) RJ45 socket on the other end, along with a locking gland for a watertight fit.
3	Adapter cable with a RayNet (male) plug on one end, and an RJ45 SeaTalkhs [®] waterproof (male) plug on the other end.
4	Adapter cable with a RayNet (male) plug on one end, and an RJ45 SeaTalkhs [®] (male) plug on the other end.
5	Adapter cable with a RayNet (female) socket on one end, and an RJ45 SeaTalkhs [®] waterproof (male) plug on the other end.
6	Adapter cable with a RayNet (female) socket on one end, and an RJ45 SeaTalkhs [®] (male) socket on the other end.

9.4 SeaTalkng® cables and accessories

SeaTalkng® cables and accessories for use with compatible products.

Part Number	Description	Details
T70134	Starter kit	Includes: • 1 x 5 Way connector (A06064) • 2 x Backbone terminator (A06031) • 1 x 3 m (9.8 ft) spur cable (A06040) • 1 x Power cable (A06049)
A25062	Backbone Kit	Includes: • 2 x 5 m (16.4 ft) Backbone cable (A06036) • 1 x 20 m (65.6 ft) Backbone cable (A06037) • 4 x T-piece (A06028) • 2 x Backbone terminator (A06031) • 1 x Power cable (A06049)
A06038	Spur cable 0.4 m (1.3 ft)	
A06039	Spur cable 1 m (3.3 ft)	
A06040	Spur cable 3 m (9.8 ft)	
A06041	Spur cable 5 m (16.4 ft)	
A06042	Elbow spur cable 0.4 m (1.3 ft)	
A06033	Backbone cable 0.4 m (1.3 ft)	
A06034	Backbone cable 1 m (3.3 ft)	
A06035	Backbone cable 3 m (9.8 ft)	
A06036	Backbone cable 5 m (16.4 ft)	
A06068	Backbone cable 9 m (29.5 ft)	
A06037	Backbone cable 20 m (65.6 ft)	
A06043	SeaTalkng® to bare wire spur cable 1 m (3.3 ft)	
A06044	SeaTalkng® to bare wire spur cable 3 m (9.8 ft)	
A06049	Power cable 1 m (3.3 ft)	
A06077	Right angled connector	90° right angle spur connector.
A06031	Terminator	
A06028	T-piece	Provides 1 x spur connection
A06064	5-way connector block	Provides 3 x spur connections
A06030	Backbone extender	
E22158	SeaTalk to SeaTalkng® converter kit	Allows the connection of SeaTalk devices to a SeaTalkng® system.
A80001	Inline terminator	Provides direct connection of a spur cable to the end of a backbone cable. No T-piece required.
A06032	Spur blanking plug	
R12112	ACU / SPX SeaTalkng® spur cable 0.3 m (1.0 ft)	Connects an SPX course computer or an ACU to a SeaTalkng® backbone.

Part Number	Description	Details
A06047	SeaTalk (3 pin) to SeaTalkng [®] adaptor cable 0.4 m (1.3 ft)	
A22164	SeaTalk to SeaTalkng [®] spur cable 1 m (3.3 ft)	
A06048	SeaTalk2 (5 pin) to SeaTalkng [®] adaptor cable 0.4 m (1.3 ft)	
A06045	SeaTalkng [®] to DeviceNet (Female) adaptor cable 0.4 m (1.3 ft)	Allows the connection of NMEA 2000 devices to a SeaTalkng [®] system.
A06075	SeaTalkng [®] to DeviceNet (Female) adaptor cable 1 m (3.3 ft)	Allows the connection of NMEA 2000 devices to a SeaTalkng [®] system.
A06046	SeaTalkng [®] to DeviceNet (Male) adaptor cable 1.5 m (4.92 ft)	Allows the connection of NMEA 2000 devices to a SeaTalkng [®] system.
A06076	SeaTalkng [®] to DeviceNet (Male) adaptor cable 1 m (3.3 ft)	Allows the connection of NMEA 2000 devices to a SeaTalkng [®] system.
A06078	SeaTalkng [®] to DeviceNet (Male) adaptor cable 0.1 m (0.33 ft)	Allows the connection of NMEA 2000 devices to a SeaTalkng [®] system.
E05026	DeviceNet (Female) to bare wires adaptor cable (0.4 m (1.3 ft)	Allows the connection of NMEA 2000 devices to a SeaTalkng [®] system.
E05027	DeviceNet (Male) to bare wires adaptor cable (0.4 m (1.3 ft)	Allows the connection of NMEA 2000 devices to a SeaTalkng [®] system.

Index

A

Accessories	74
Network adapter cables	76
Network cables	76
RayNet cables	76
SeaTalkng cables	78
Accessory connection	47
Adaptor plates	74
Axiom™+ MFDs	14

C

Cable extension	46
Card reader connection	47
CHIRP transducers	17
Cleaning	50
Screen	51
Compass safe distance	25
Conical beam transducers	17
Connecting cables	38
Connection	
NMEA 2000	45
Power	39
SeaTalkng	45
Transducer	45
Connections	38
Accessory	47
Battery	41
Card reader	47
Distribution panel	40
Ethernet	47
External storage	47
Network	47
RayNet	47
RCR	47
SeaTalkhs	47
USB (via RCR-SDUSB)	47
Connectors	38
Contact details	66

D

Declaration of Conformity	11
Dedicated grounding	44
DeviceNet cables	79
Diagnostics	67
Dimensions	
Axiom 12 flush mount	30
Axiom 12 surface mount	30
Axiom 12 trunnion mount	29
Axiom 7 flush mount	28
Axiom 7 surface mount	28
Axiom 7 trunnion mount	28
Axiom 9 flush mount	30
Axiom 9 surface mount	30
Axiom 9 trunnion mount	29
DownVision™ transducers	17

E

Electromagnetic Compatibility	24
-------------------------------------	----

EMC, <i>See</i> Electromagnetic Compatibility	
Ethernet connection	47
External storage connection	47

F

Factory reset	55
Fuse rating	39

I

Installation	
Best practice	43
Flush mounting	35
Flush mounting — Axiom 7 only	33
Mounting options	31
Rear brackets	35
Surface mounting	35
Surface mounting — Axiom 7 only	33
Trunnion mounting	31
Interference	25
<i>See also</i> Compass safe distance	
RF	25
IP address	67

L

Legacy adaptor	14
LightHouse 3	14
LightHouse™ 3	
Tips and Tricks	68
Location requirements	
General	24
GNSS	25
GPS	25
Touchscreen	27
Viewing angle	27
Wireless	27

M

Maintenance	50
Mounting options	31

N

Network connection	47
--------------------------	----

O

Operation instructions, LightHouse 3	14
--	----

P

Parts supplied	
Axiom 12 (DISP)	21
Axiom 12+	20
Axiom 7+	19
Axiom 7+ (DISP)	19
Axiom 9 (DISP)	21
Axiom 9+	20
Power	

Battery connection.....	41
Distribution	40
Distribution panel.....	40
Grounding.....	43
Sharing a breaker	40
Power cable extension	42
Power connection	39
Power troubleshooting	55
Product information.....	67
Product recycling (WEEE)	11
Product support.....	66
Product variants.....	14

R

Radio Frequency (RF) interference.....	25
RayNet	
cables	76
RayNet connection	47
RCR-SDUSB.....	14
RealVision™ transducers	16
Recovery mode	55
Removing trunnion adaptor.....	33
Routine checks	50

S

SeaTalkhs connection	47
SeaTalkng cables	78
Service Center.....	66
Servicing.....	50
Spares	75
Support forum	68

T

Technical specification	69
Connections.....	70
Environmental.....	70
GNSS receiver	71
LCD	70
Power.....	70
Storage	71
Technical Specification	
RealVision 3D Sonar	71
Technical support.....	66, 68
Thermal breaker rating.....	39
Training courses.....	68
Transducer	
Adaptor cables	46, 74
Transducer connections.....	38
Transducers	
CHIRP	17
Conical beam.....	17
TransducersDownVision™	17
TransducersRealVision™	16
Troubleshooting	54
GNSS (GPS).....	56

V

Ventilation	24
Video Gallery.....	68

W

Warranty	66
WEEE Directive	11
Wireless	
Interference	27



Raymarine

Marine House, Cartwright Drive, Fareham, Hampshire.
PO15 5RJ. United Kingdom.

Tel: +44 (0)1329 246 700

www.raymarine.com

Raymarine®

a brand by  **FLIR®**